
# THE INSTALLER'S HANDBOOK FOR HEATING SYSTEMS CONTROLLED WITH ACVMAX

# VOLUME 0 Introduction



Prestige 24 - 32 Solo / Excellence Prestige 42 - 50 - 75 - 100 - 120 Solo HeatMaster 25 C HeatMaster 25 - 35 - 45 - 70 - 85 - 120 TC WaterMaster 25 - 35 - 45 - 70 - 85 - 120

Applicable to appliances manufactured from March 2016, equipped with at least software version (DSP) 3.05



#### **VOLUME 0 - INTRODUCTION**

RECOMMENDATIONS	0-3
Important instructions - read before proceeding	
Applicability	0-3
USER'S GUIDE	0-4
How to use this manual	
VOLUME 1 - ACVMAX MENUS AND FUNCT	IONS
ACVMAX DESCRIPTION AND OPERATION	1-3
ACVMax Operating information	
Control panel description	
Home page description	1-3
Appliance Easy setup (EZ Setup)	1-4
Selecting the language	
Installer Code	1-4
Installer menu structure	
Installer menu description	1-5
ACVMAX PARAMETERS FOR THE SPECIALIST	1-23
List of Status Line Messages	1-23
Appliance codes	
Factory settings and reset values	
ACVMax menu structure	1-25
<b>VOLUME 2 - SYSTEM DIAGRAMS AND ACV</b>	MAX SETUP
USER'S GUIDEGeneral	
Resistance of the temperature sensors	
PRESTIGE SOLO/EXCEL (3-WAY VALVE)	
Electrical Characteristics Prestige 24-32 Solo/Excellence Pumps (Prestige Solo/Excel (3-Way valve))	
Preset Configuration 1	
Preset Configuration 2	
Preset Configuration 3	
Preset Configuration 4	
PRESTIGE SOLO (2 PUMPS)	
Electrical Characteristics Prestige 42 - 50 - 75 Solo	
Electrical Characteristics Prestige 100-120 Solo	
Pumps (Prestige Solo)	
Preset Configuration 1	
Preset Configuration 4	
Preset Configuration 3	
Preset Configuration 7	
Preset Configuration 9	
Preset Configuration 12	

HEATMASTER AND WATERMASTER	2-29
Electrical Characteristics HeatMaster® 25-35-45 TC, HeatMaster® 25 C and WaterMaster 2	
Electrical Characteristics of HeatMaster® 70-85 TC, WaterMaster 70 - 85	
Electrical Characteristics of HeatMaster® 120 TC, WaterMaster 120120	
Pumps (HeatMaster)	
Pumps (WaterMaster)	
HEATMASTER	
Preset Configuration 16	
Preset Configuration 15 Preset Configuration 15	
	2-30
VOLUME 3 - CASCADE SYSTEMS	
GENERAL INFORMATION	3-3
User's Guide	
Operating Principles of an ACVMax-Controlled Cascade	
MENUS AND SCREENS DESCRIPTION	
Structure of the ACVMax cascade menu	
INSTALLATION OF THE CASCADE BOILERS	3-1
General process for cascade installation	
INSTALLATION AND CONFIGURATION OF CASCADE SYSTEMS	
Assembling the Cascade Mounting rack	
Hydraulic connections of Cascade Systems	
Chimney connections of Cascade Systems	
Cascade start-up process	
Accessing the Cascade Autodetection page	
Preset Configuration 2	
Preset Configuration 5	3-24
VOLUME 4 - CHIMNEY CONNECTIONS	
CHIMNEY CONNECTION CHARACTERISTICS FOR PRESTIGE BOILERS	4-3
CALCULATION OF FLUE PIPE SYSTEM - PRESTIGE APPLIANCES	
Calculation of the Flue Pipe Length	
Prestige Solo Cascade : maximum length of flue pipes	
CHIMNEY CONNECTION CHARACTERISTICS FOR HEATMASTER AND	
MASTER APPLIANCES	
CALCULATION OF FLUE PIPE SYSTEM - HEATMASTER AND WATERMAS	
Calculation of the flue pipe length	4-
HeatMAster/WaterMaster Cascade: maximum length of flue pipes	4-8
VOLUME 5 - TROUBLESHOOTING	
BLOCKAGE AND ERROR CODES	5-3

#### RECOMMENDATIONS

#### NOTE

This manual contains important information with respect to the installation and set-up of the boiler.

This manual must be provided to the installer, who will keep it in a safe place.

We accept no liability should any damage result from the failure to comply with the instructions contained in this technical manual.



#### Essential recommendations for safety

- It is prohibited to carry out any modifications to the appliance without the manufacturer's prior and written agreement.
- The appliance must be set up by a qualified installer, in accordance with applicable standards and regulations.
- The installation must comply with the instructions contained in the boiler's installation manual and with the standards and regulations applicable to installations.
- Failure to comply with the instructions in this manual could result in personal injury or a risk of environmental pollution.
- The manufacturer declines all liability for any damage caused as a result of incorrect installation or in the event of the use of appliances or accessories that are not specified by the manufacturer.



Essential recommendations for the correct operation of the appliance

- To guarantee the correct operation of the installation, it is essential to carry out the adjustments in accordance with the instructions in this manual.
- In order to ensure that the appliance operates correctly, it is essential to inspect and service the boiler every year.
- Faulty parts may only be replaced by genuine factory parts.



#### General remark

The manufacturer reserves the right to change the technical characteristics and features of its products without prior notice.

#### IMPORTANT INSTRUCTIONS - READ BEFORE PROCEEDING



Essential recommendations for safety

- This document is intended to be used by a factory trained and qualified heating contractor or service technician only. Read all instructions within this document and within the concerned appliance's Installation, Operation and Maintenance Manual before proceeding.
- It is recommended to follow the procedures in the steps given. Skipping or missing procedural steps could result in severe personal injury, death or substantial property damage.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless supervised or unless they have been given instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

#### **APPLICABILITY**

This manual is applicable to appliances manufactured from March 2016 and equipped with an ACVMax controller running at least on software version 3.05.



To know the software version of the controller installed in your appliance, look at the information displayed just after the ON/OFF master switch has been pushed in to turn the appliance on.

Software version 3.03 does not support the appliance coding function. Please refer to the ACVMax System Control manual on the ACV website (ref. 660Y2800).

#### If you smell gas:

- Immediately isolate the gas supply.
- Open windows and doors to ventilate the area.
- Do not use any electrical appliances and do not operate any switches.
- Immediately notify your gas supplier and/or your installer.



#### **HOW TO USE THIS MANUAL**

The Installer's Handbook is for the exclusive use of ACV-approved installers.


The manual is comprised of 6 volumes, containing each all relevant information to set up a complete system based on an appliance controlled with ACVMax.

- Volume 0 contains the general recommendations and an interactive table of contents for all the volumes.
- Volume 1 gives a general description of the ACVMax, as well as a detailed description of all the screens, menus and parameters, with the exception of the ACVMax menus (see Volume 3).
- Volume 2 presents typical hydraulic diagrams for different system configurations, as well as the parameter settings for each configuration.
- Volume 3 provides all required information to set up a cascade system (Prestige Solo boilers only), i.e. electrical connection, hydraulic connection, chimney connection and the Cascade start up through the Cascade Autodetection function.
- Volume 4 gives information on the various chimney connections according to the selected chimney type.
- Volume 5 contains the blockage and error codes displayed on the ACVMax screen, which will allow the installer to troubleshoot the possible faults.

For any other heating system configuration than those in this manual, please contact your ACV representative.

# THE INSTALLER'S HANDBOOK FOR HEATING SYSTEMS CONTROLLED WITH ACVMAX

# VOLUME 1 ACVMax Menus and Functions



Prestige 24 - 32 Solo /Excellence
Prestige 42 - 50 - 75 - 100 - 120 Solo
HeatMaster 25 C
HeatMaster 25 - 35 - 45 - 70 - 85 - 120 TC
WaterMaster 25 - 35 - 45 - 70 - 85 - 120

Applicable to appliances manufactured from March 2016, equipped with at least software version (DSP) 3.05



#### **VOLUME 1 - ACVMAX MENUS AND FUNCTIONS**


ACVMAX DESCRIPTION AND OPERATION	1-3
ACVMax Operating information	1-3
Control panel description	
Home page description	
Appliance Easy setup (EZ Setup)	
Selecting the language	
Installer Code	
Installer menu structure	
Installer menu description	1-5
CH & DHW Settings ( )> CH Settings ( )> CH & DHW Settings ( )> DHW Setting ( )>	1-6
CH & DHW Settings (10)>> DHW Setting (10)	1-12
CH & DHW Settings ( Boiler Settings ( CH & DHW	1-16
Reset all settings ( )	
Cascade Menu ( Cascad	1-21
Manual Operation (	1-22
ACVMAX PARAMETERS FOR THE SPECIALIST	1-23
List of Status Line Messages	
Appliance codes	
Factory settings and reset values	
ACVMax menu structure	



#### **ACVMAX OPERATING INFORMATION**

The ACVMax system control is designed to be flexible yet easy to use. It monitors and controls the appliance to operate as efficiently as possible. ACVMax monitors the appliance supply, return and flue gas temperatures and operates the igniter, gas valve and blower. It uses this information to modulate the appliance firing rate to maintain the required setpoint. ACVMax offers many advanced control options, which may be adjusted for various applications to achieve optimum appliance efficiency and operation:


- Two central / space heating (CH) call inputs with separate outdoor curves.
- A Domestic Hot Water (DHW) call input with optional priority.
- System temperature sensing and control with an optional system temperature sensor.
- A cascade function. It allows up to four Prestige Solo (2 pumps) boilers to operate together in a single heating system.



• A Modbus interface for integrating with building management systems.

These advanced features are adjustable in the Installer Menu after entering an access code. Refer to "Installer Code" for more details.

#### **CONTROL PANEL DESCRIPTION**



- ACVMax LCD Display It is the setup interface of the appliance and indicates the parameter values, the error codes and the set-up status of the parameters. It displays a series of screens, each showing information and/or icons. The main icons are detailed on the right.
- 2. **Installer button** Allows the installer to access the menus of the ACVMax controller to set up the system.
- 3. **Arrow keys and OK key** To browse through the screens of the ACVMax controller, set up the appliance, increase and decrease the displayed values and validate the selections and access the Easy set-up screens. The OK key is also used to RESET the appliance after a blocking (following the instructions on the screen.

#### Main settings of ACVMAX Display

- Screen backlight it will illuminate when any button is depressed, and remain illuminated for five minutes
- Screen contrast it can be adjusted at the Home screen by pressing and holding the OK button, then
  pressing and holding the LEFT button along with the OK button. Press the UP and DOWN button to
  increase or decrease the contrast while holding the OK and LEFT buttons depressed. All buttons must
  be released and the procedure performed again to switch between increasing and decreasing contrast.

#### Main Icons of ACVMax display

Central Heating - indicates information related to the CH circuit.

**DHW** - indicates information related to the Domestic Hot Water circuit.

**home** - to go back to the main menu screen.

**Back** - to go back to the previous screen.

Pump - indicates a pump is operating.

**Warm weather shutdown** - displays on the home screen when the outdoor temperature reaches the Warm Weather Shutdown preset temperature.

#### **HOME PAGE DESCRIPTION**

The **appliance type** is indicated at the top of the screen. The type and model are factory preset. This setting can be accessed through the installer menu (Boiler settings > Appliance settings) and modified using an appliance code (e.g. in the case of a gas conversion or an ACVMax board replacement).


#### Refer to "Appliance codes"

The appliance is represented in the centre of the Home Screen. Basic operating information such as supply and return temperatures are displayed as well as current burner status.

**Radiator icon:** indicates that a central heating call has been received. A small number 1 or 2 indicates which CH calls are active.

A **flame symbol** is displayed when the unit is fired. The flame size changes to indicate the current firing rate.

**Basic information**. The user can toggle the items using the LEFT and RIGHT keys and view target, Supply, Return, Domestic, Outdoor and System temperatures.



**Tap icon:** indicates that a DHW call has been received.

**Circulator icons:** indicate which circulators are currently powered.

**Status line**: displays the current operating state of the appliance.


See "List of Status Line Messages".



#### **APPLIANCE EASY SETUP (EZ SETUP)**

The main parameters of the appliance can be set up using the EZ (easy) setup function of the controller. The EZ setup function allows the user/installer to quickly setup the appliance for immediate operation according to the system configuration. Refer to the appliance "Installation, Operation and Maintenance Instructions".

#### **SELECTING THE LANGUAGE**



#### **INSTALLER CODE**

Through the use of the specific code "**054**", the installer can access various setup screens, in order to define a large set of parameters and adapt the operation of the ACVMax to the system configuration.


To navigate on the screen, use the **UP, DOWN, LEFT** and **RIGHT** keys, (SIGNE) then the **OK** key to validate a selection. To increase/decrease values, use the **UP** and **DOWN** keys. or to the situation.



#### **General remarks**

- Entering the installer access code allows the installer to make adjustments for 30 minutes. After 30 minutes, the access code will need to be entered again to make any adjustments.
- If the end user misuses the installer code to access installer-specific parameters and makes changes that cause a system failure, any warranty claim will be void.

#### **INSTALLER MENU STRUCTURE**



#### **INSTALLER MENU DESCRIPTION**

The installer Menu contains the following icons:

- 1. CH & DHW Settings Allows the installer to adjust the appliances central/space heating and domestic hot water settings for the application. For the detail of the menus, go to "CH & DHW Settings".
- 2. Manual Operation The burner and circulators can be manually enabled for testing. For a detail of the menus, go to "Manual Operation (())".
- Cascade Settings Allows the installer to setup, adjust and monitor the Cascade System. For a detail of the menus, go to "menus and screens description" in Volume 3.
- 3. Reset All Settings Resets all CH, DHW, and Cascade Settings back to the default settings (for the detail of the values, go to "Factory settings and reset values"). For a detail of the menus, go to "Reset all settings ( )".
- 5. **A Home** to go back to the home page.
- 6. Back to go back to the previous screen.



To navigate on the screen, use the **UP, DOWN**,

LEFT and RIGHT keys, ( ) then the OK key to validate a selection. To increase/decrease values, use the UP and DOWN or LEFT and RIGHT keys, according to the situation

CH & DHW Settings

CH Settings

CH Settings

Heating Settings


Heating Operation

Enabled

Demand Thermostal & Satropin

"Installer Code"

The **Heating Settings** menu contains settings related to central heating operation. Each line contains a CH Setting followed by its current value. Six CH Settings are displayed on the screen at one time



**Heating Operation** allows the central heating function to be enabled and disabled.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the **OK** button to store the setting.

**Enabled** - The Appliance will respond to a central heating call.

Disabled - The Appliance will not respond to a central heating call. The heating operation disabled icon ( ) is displayed on the home screen when central heating operation has been disabled.

When heating is disabled the frost protection will still be active.


**Default: Enabled** 

**Demand Type** allows the installer to select how a CH Demand is generated.

Press the **UP** or **DOWN** buttons to select the CH Demand Type then press the **OK** button to store the setting.

Default: Thermostat and Outd. Curve

See detail of menu on next page.



**Demand Type** screen menu

**Thermostat & Outdoor Curve** – A central heating call from a dry contact switch will enable the appliance and the setpoint will vary with the outdoor temperature for central heating calls.


Thermostat & Setpoint - A central heating call from a dry contact switch will enable the appliance and the setpoint will be fixed for central heating calls.


**Constant & Outd. Curve** - The appliance will maintain setpoint and the central heating circulators will be constantly enabled without an external call from a dry contact switch. The central heating circulators will be disabled when the outdoor temperature exceeds the Warm Weather Shutdown Temperature setting. The setpoint will vary with the outdoor temperature for central heating calls.

**Constant & Setpoint** - The appliance will maintain setpoint and the central heating circulators will be constantly enabled without an external call from a dry contact switch. The central heating circulators will be disabled when the outdoor temperature exceeds the Warm Weather Shutdown Temperature setting. The setpoint will be fixed for central heating calls.

**0 - 10V Modulation Signal** - This option allows the appliance firing rate to be controlled by an external control system. Based on the control input voltage, the appliance will start to operate for heat demand. The CH temperature is limited by the Absolute maximum temperature (87°C).

- 0 2V appliance is off.
- 2 10 V linear power increase from minimum to maximum output.
- $10-2\,\mathrm{V}$  linear power decrease from maximum to minimum output.
- 2 1 V appliance on minimum capacity.
- 1 0 V appliance off.





**CH Maximum Capacity** limits the maximum CH capacity. The appliance capacity can be defined by adjusting this value, 100% means Maximum CH output, 0% means minimum CH output. It is therefore possible to adjust the CH capacity to the installation needs.

Example: when set to 60%, the real appliance capacity is the appliance minimum capacity plus 60% of the difference between the maximum and minimum capacity.

Press the **LEFT** or **RIGHT** buttons to adjust the CH Maximum Capacity, then press the **OK** button to store the setting.

Default: 100%

**Absolute Max CH Setpoint** limits the setpoint during a central heating call. This setting can be used to prevent a user from adjusting the central heating setpoint or outdoor curve above a safe operating temperature in the EZ Setup Menu. A warning screen will be displayed in EZ Setup if the user attempts to raise the setpoint above the Absolute Max CH Setpoint. The Absolute Max CH Setpoint will be displayed on the outdoor curve in EZ Setup if the user selects an outdoor curve which goes above the Absolute Max CH Setpoint.

Press the **LEFT** or **RIGHT** buttons to adjust the Absolute Max CH Setpoint then press the **OK** button to store the setting.

Default: 87°C

**CH1 Max. Setpoint** is the maximum setpoint for a CH1 heating call when an Outdoor Curve option is chosen in Demand Type. CH1 Maximum Setpoint is the fixed setpoint for a CH1 heating call when a Setpoint option is chosen in Demand Type.


Press the **LEFT** or **RIGHT** buttons to adjust the CH1 Maximum Setpoint then press the **OK** button to store the setting.


Default: 82°C

**CH1 Min. Setpoint** is the minimum setpoint for a CH1 heating call when an Outdoor Curve option is chosen in Demand Type. This setting is not applicable when a Setpoint option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the CH1 Minimum Setpoint then press the **OK** button to store the setting.

Default: 27°C





**Outdoor Curve Coldest Day** is the coldest outdoor design temperature of the heating system when an Outdoor Curve option is chosen in Demand Type. This setting is not applicable when a Setpoint option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the Outdoor Curve Coldest Day then press the **OK** button to store the setting.

Default: -12°C

**Outdoor Curve Warmest Day** is the warmest outdoor design temperature of the heating system when an Outdoor Curve option is chosen in Demand Type. This setting is not applicable when a Setpoint option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the Outdoor Curve Warmest Day then press the **OK** button to store the setting.

Default: 18°C



The temperatures of Outdoor Curve Coldest Day and Outdoor Curve Warmest Day are identical to those of CH1.

CH2 Circuit allows the CH2 heating call to be enabled and disabled.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the **OK** button to store the setting.

**Enabled** – The appliance will respond to a CH2 heating call


**Disabled** – The appliance will not respond to a CH2 heating call

**Default: Enabled** 

**CH2 Maximum Setpoint** is the maximum setpoint for a CH2 heating call when an Outdoor Curve option is chosen in Demand Type. CH2 Maximum Setpoint is the fixed setpoint for a CH2 heating call when a Setpoint option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the CH2 Maximum Setpoint then press the **OK** button to store the setting.

Default: 60°C



**CH2 Minimum Setpoint** is the minimum setpoint for a CH2 heating call when an Outdoor Curve option is chosen in Demand Type. This setting is not applicable when a Setpoint option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the CH2 Minimum Setpoint then press the **OK** button to store the setting.

Default: 27°C

**Warm Weather Shutdown** allows to enter an optional outdoor temperature at which to disable the central heating function. The Appliance will continue to respond to a domestic hot water call or a 0-10V Modulation Signal when the outdoor temperature exceeds the Warm Weather Shutdown Temperature setting.

Press the **LEFT** or **RIGHT** buttons to adjust the Warm Weather Shutdown Temperature then press the **OK** button to store the setting and complete the Heating setting.

The Warm Weather Shutdown icon ( is displayed on the home screen when the outdoor temperature reaches the Warm Weather Shutdown Temperature.

Default: OFF.

**Circulation Pump Permanent** allows the central heating circulators to be constantly enabled even without a central heating call. A domestic hot water call will cause the circulators to be disabled during the domestic call as long as DHW Priority is enabled.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the OK button to store the setting.


- Enabled The central heating circulators will be enabled for constant circulation without a central heating call.
- **Disabled** The central heating circulators will only be enabled during a central heating call.

**Default: Disabled** 

**CH Post Pump Time** sets how long the central heating circulators will continue to operate at the completion of a heating call. Refer to the relevant "Pumps" section of Volume 2, to know which pumps will continue to operate. Any call during the CH Post Pump Time will be ignored until the post pump has completed. The CH Post Pump Time feature allows the heat remaining in the appliance at the completion of a call to be sent to the heating system, which will improve the overall efficiency of the system.

Press the **LEFT** or **RIGHT** buttons to adjust the CH Post Pump Time then press the **OK** button to store the setting.

Default: 5 min



The **Freeze Protection** menu allows the feature to be enabled and disabled. The built-in frost protection mechanism activates the system pumps as soon as the flow temperature [NTC1 probe] drops below 7°C. As soon as the flow temperature is at 5°C, the burner starts up until the flow temperature rises above 15°C. The pumps continue to run for around 10 minutes.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the **OK** button to store the setting.

- Enabled The Frost Protection feature protects the installation from freezing at a predetermined system flow temperature.
- **Disabled** The Frost Protection feature is disabled. Only the pumps operate.

**Default: Enabled** 

**Frost Protection Setpoint** allows to define the outside air temperature at which the anti-freeze function is activated (only available if an outdoor temperature sensor is connected). The pumps are activated when the outside temperature drops below the threshold defined in this menu.

Press the **LEFT** or **RIGHT** buttons to adjust the Freeze temperature Setpoint then press the **OK** button to store the setting.



In order to enable the protection of the whole system against freezing, all the valves of the radiators and the convectors should be completely open.

Default: -30°C

**Parallel Shift** allows the CH setpoint to be externally adjusted when a Constant option is chosen in Demand Type. When a Constant option is chosen in Demand Type, continuous CH1 and CH2 heating calls are generated. Simultaneous CH1 and CH2 calls will result in the Appliance operating at the highest CH1 or CH2 setpoint. The CH1 or CH2 Thermostat terminals with the highest setpoint will be used to adjust the setpoint. If the Thermostat terminals with the highest setpoint are open, the CH setpoint will decrease by the Parallel Shift Value. If the Thermostat terminals with the highest setpoint are closed, the CH setpoint will return to the highest CH1 or CH2 setpoint

Press the **LEFT** or **RIGHT** buttons to adjust the Parallel Shift Value then press the **OK** button to store the setting.


Default: 0°C

**CH Call Blocking** sets the minimum time between burner firings for central heating calls. At the completion of a burner firing, the CH Call Blocking time will begin. The burner will not fire again until after the CH Call Blocking time has elapsed. The CH Call Blocking time only prevents the burner from firing, the central heating circulators will respond to a central heating call. This blocking time has no affect on domestic hot water calls. The CH Call Blocking feature prevents short cycling of the burner and extends the life of the burner components.

Press the **LEFT** or **RIGHT** buttons to adjust the Parallel Shift Value then press the **OK** button to store the setting.

Default: 2 min.

### CH & DHW Settings (🗓)-->> DHW Setting (🗓 🖜



DOWN, LEFT and RIGHT keys, (IX) then the **OK** key to validate **☑** a selection. To increase/decrease values, use the UP and DOWN keys, or LEFT and RIGHT,

**DHW Operation** allows the domestic hot water function to be enabled and disabled.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the **OK** button to store the setting.

- Enabled The Appliance will respond to a domestic hot water call.
- Disabled The Appliance will not respond to a domestic hot water call. The domestic hot water operation disabled icon ( is displayed on the home screen when domestic hot water operation has been disabled.


**DHW Operation default: Enabled** 

**Demand Type** allows the installer to select the type of device which will generate a domestic hot water call.

Press the **UP** or **DOWN** buttons to select the DHW Demand Type then press the **OK** button to store the setting.

The DHW Demand options are:

- Thermostat A domestic hot water call from an aquastat or dry contact switch will enable the Appliance with a fixed setpoint for a domestic hot water call.
- Sensor This option requires the use of an Indirect Water Heater Sensor. The Appliance will monitor the DHW storage temperature and generate a domestic hot water call when the temperature drops below the DHW Storage Setpoint - DHW On Differential.



**DHW Boiler Setpoint** is the fixed appliance setpoint temperature during a domestic hot water call when the Thermostat option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Boiler Setpoint then press the **OK** button to store the setting.

Default: 75°C

**DHW Setpoint** is the domestic hot water storage setpoint temperature when the Sensor option is chosen in Demand Type.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Setpoint then press the **OK** button to store the setting.

Default: 60°C



The appliance setpoint is automatically set to the DHW Setpoint + DHW Storage adder when the Sensor option is chosen in DHW demand

**DHW On Differential** sets how far the DHW storage temperature must fall below the DHW Storage Setpoint to create a domestic hot water call when the Sensor option is chosen in Demand Type. The domestic hot water call will end when the DHW storage temperature rises above the DHW Storage Setpoint.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW On Differential then press the **OK** button to store the setting.

Default: 3°C




The DHW on differential setting greatly affects the production of domestic hot water. A low setting could result in a rapid response to a domestic hot water call resulting in a potential scald hazard. It is strongly recommended that the installer use a thermostatic mixing valve on the hot water outlet of the Indirect Water Heater. Failure to comply could result in severe personal injury, death, or substantial property damage.

**DHW Storage Adder** is used to compute the appliance setpoint when the Sensor option is chosen in Demand Type. The appliance setpoint will be DHW Storage Setpoint + DHW Storage Adder for a domestic hot water call.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Storage Adder then press the **OK** button to store the setting.

Default: 15°C



**DHW Post Pump Time** sets how long the domestic hot water circulator will continue to operate at the completion of a domestic hot water call. Any call during the DHW Post Pump Time will be ignored until the post pump has completed. The DHW Post Pump feature allows the heat remaining in the appliance at the completion of a call to be sent to the Indirect Water Heater, which will improve the overall efficiency of the system.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Post Pump Time then press the **OK** button to store the setting.

Default: 1 min.

**DHW Priority Timeout** allows the installer to enter an optional time limit that a domestic hot water call has priority over a central heating call when DHW Priority is set to Enabled.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Priority Timeout then press the **OK** button to store the setting.

Default: Off

**DHW Priority** allows the domestic hot water priority function to be enabled and disabled.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the **OK** button to store the setting.

- **Enabled** Domestic hot water calls will have priority over a central heating call. The appliance setpoint will be set to the domestic hot water setpoint during a domestic hot water call. The DHW circulator will be enabled and the heating circulators will be disabled during a domestic hot water call.
- **Disabled** Domestic hot water calls will not have priority over a central heating call. The appliance setpoint will be set to the domestic hot water setpoint when only a domestic hot water call is present. The appliance setpoint will be set to the highest setpoint when simultaneous domestic hot water and central heating calls are present. The DHW circulator will be enabled during a domestic hot water call. The heating circulators will be enabled during a central heating call.

#### **Default: Enabled**




Simultaneous domestic hot water and central heating calls will result in the Appliance operating at the highest target temperature when DHW Priority is set to disabled. The use of a mixing device on the lower temperature zones may be required to protect the lower temperature zones from damage.

**DHW Call Blocking** sets the minimum time between burner firings for domestic hot water calls. At the completion of a burner firing, the DHW Call Blocking time will begin. The burner will not fire again until after the DHW Call Blocking time has elapsed. The DHW Call Blocking time only prevents the burner from firing, the domestic hot water circulator will respond to a domestic hot water call. This blocking time has no affect on central heating calls. The DHW Call Blocking feature prevents short cycling of the burner and extends the life of the burner components.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Call Blocking time then press the **OK** button to store the setting.

Default: 0 min.



**DHW To CH Call Blocking** sets the minimum time between a DHW burner firing and a CH burner firing. At the completion of a DHW burner firing, the DHW to CH Call Blocking time will begin. The burner will not fire again for a central heating call until after the DHW To CH Call Blocking time has elapsed. This feature only prevents the burner from firing, the central heating circulators will respond to a central heating call. This blocking time has no affect on domestic hot water calls. The DHW To CH Call Blocking feature prevents the burner from firing when switching from a domestic hot water call to a central heating call. This allows the remaining heat in the heat exchanger to be dissipated and potentially satisfy the central heating call.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW To CH Call Blocking time then press the **OK** button to store the setting.

Default: 1 min.

The **Antilegionella Function** ensures that an Indirect Water Heater is heated at least once per week to prevent the growth of Legionella bacteria.

Press the **UP** or **DOWN** buttons to select Enabled or Disabled then press the **OK** button to store the setting.

• **Enabled**- When the **Thermostat** option is chosen in Demand Type, a domestic hot water call is generated for 15 minutes once per week to heat the Indirect Water Heater.

When the **Sensor** option is chosen in Demand Type, a domestic hot water call is generated until the DHW storage temperature reaches 60°C once per week. When the Sensor option is chosen in Demand Type, the weekly timer is reset whenever the DHW storage temperature reaches 60°C to prevent unnecessary firings. This function will be active even if DHW Operation has been set to Disabled. The appliance setpoint is at 80°C during the antilegionella cycle.

• Disabled - The Appliance will only fire in DHW mode when a domestic hot water call is received.

#### **Default: Enabled**





The antilegionella function should only be enabled when an Indirect Water Heater is installed. Enabling the antilegionella function without an Indirect Water Heater will result in the Appliance firing once per week in DHW mode. This could cause a Manual Reset Hard Lockout of the appliance.



The antilegionella function is most effective when the Sensor option is chosen in DHW demand. The use of an Indirect Water Heater Sensor ensures that the domestic hot water is heated to 60°c at least once per week.







The **Pump Settings** menu allows to choose the right pump configuration to the chosen hydraulic configuration.

The **Current Pump Config** indicates which configuration is currently selected for the appliance.


Two appliance configuration modes are available: a preset configuration mode and a flexible configuration mode.

Press the **UP** or **DOWN** buttons to scroll through the options, then on **OK** to validate your selection.




In the **Preset Pump Config.** (preferred selection) you can choose from a number of preset pump configurations. Only the configurations usable with a certain model/type of appliance will appear in the list. The configurations are detailed in Volume 2, "User's Guide". Each configuration is detailed through one or several hydraulic diagrams, a table indicating the electrical connections and a list of the parameters to be defined in ACVMax.

Press the **UP** or **DOWN** buttons to scroll through the settings, then on **OK** to validate your selection.




The **Flexible Pump Config.** menu allows to customize the pump configuration to the chosen hydraulic configuration. Only select this option when the preset configurations do not offer you a solution. In this menu you have to choose per relay for which heat demand / function it will be activated. The relays are allocated as follows by default (see picture below for physical location on the optional terminal blocks):


\*\*Prestige Solo\*\*



Press the  $\bf UP$  or  $\bf DOWN$  buttons to scroll through the settings, then on  $\bf OK$  to validate your selection.

The use of the Flexible Pump Config. menu is not possible for the Solo/ Excellence (3 way valve).





Each relay function has several options. Activation will happen when one of the following options has been chosen: **CH1**, **CH2**, **DHW**, **MIX OPEN**, **MIX CLOSE**, **ERROR**, **FLAME**.

More than one action can be chosen for one relay (one relay can become active for CH1, CH2 and DHW demand when needed.)

Press the **UP** or **DOWN** buttons to scroll through the settings, then on **OK** to toggle between the On/Off status of each relay. Then go to the next line, until you reach the last line.

- When selecting **CH 1**, the relay is activated at CH 1 demand.
- When selecting CH 2, the relay is activated at CH 2 demand.
- When selecting **DHW**, the relay is activated at DHW demand.
- When selecting **Mix Open**, the Mixing valve open input is activated. Provided there is a mixing valve in the hydraulic circuit, runtime is assumed to be 120 sec.
- When selecting **Mix Close**, the Mixing valve close input is activated. Provided there is a mixing valve in the hydraulic circuit, runtime is assumed to be 120 sec.
- When selecting ERROR, the relay is activated on error.
- When selecting **FLAME**, the relay is activated when appliance is running and a flame signal has been detected.



By pushing the **RIGHT** button then **OK**, you go back to the previous screen, but THE CHANGED VALUES ARE NOT STORED in the memory (Quick escape route).

<u>To save your changes</u>, make sure to scroll down to the last line of the screen and to select **Save & Exit**. Then press on **OK** to activate the function.



CH2

DHW


MIX OPEN MIX CLOSE


FRROR

FLAME

⇑

Press on **OK** to activate **Save & Exit**. This will ensure that the changed data are stored in the appliance.





There are three possible selections to activate the **Error Relay** (alarm) contact:

- On Lockout, Blocking and Warning: the error relay is activated at a non-volatile lock-out (e.g. CH Flow NTC defect), at a blocking error (self-resetting errors) (e.g. Gas-pressure switch not closed), or at a warning (e.g. low water pressure warning).
- **On Lock-out and blocking**: the error relay is activated at a non-volatile lock-out or a blocking error.
- On Lockout: the error relay is activated at a non-volatile lock-out only.


The selection depends on the alarm feedback requirement from the customer.

The **Ignition Level** parameter allows to change the fan start speed of the appliance.


Press the **LEFT** or **RIGHT** buttons to adjust the settings, then on **OK** to validate your selection.

**Default**: See table below for each the fan speed applicable to each appliance/gas combination

Prestige	Natural Gas (G20)	Propane (G31)				
24 Solo	3000 rpm	3000 rpm				
24 Excellence	3000 rpm	3000 rpm				
32 Solo	3500 rpm	3000 rpm				
32 Excellence	3500 rpm	3000 rpm				
42 Solo	3800 rpm	3350 rpm				
50 Solo	3300 rpm	3300 rpm				
75 Solo	3700 rpm	3000 rpm				
100 Solo	2600 rpm	2600 rpm				
120 Solo	2600 rpm	2600 rpm				
HeatMaster C-TC / WaterMaster						
25	3750 rpm	3750 rpm				
35	3750 rpm	3750 rpm				
45	3750 rpm	3750 rpm				
70	3750 rpm	3750 rpm				
85	3750 rpm	3750 rpm				
120	3850 rpm	3850 rpm				



### Reset all settings (



**Reset All Settings** allows the installer to reset all CH, DHW, and Cascade settings back to the default values (Refer to <u>"Factory settings and reset values"</u> for the default settings).


Follow the on-screen instructions to reset all settings back to the factory default values.

## Cascade Menu ( )



Refer to "VOLUME 3 - Cascade Systems"

## Manual Operation ( )



FAN - Press the OK button while the FAN icon is highlighted to manually fire the burner and power the CH (1) circulator.

Press the **LEFT** and **RIGHT** buttons to adjust the firing rate from 0% (Low Fire) to 100% (High Fire).

Hold down the **LEFT** or **RIGHT** buttons to rapidly increase or decrease the firing rate.

Press the **OK** button again while the FAN icon is highlighted to shutdown the burner when finished.

CH1 - Press the OK button while the CH1 icon is highlighted to manually power the CH1 circulator(s) as in CH demand.

Press the **OK** button again while the CH1 icon is highlighted to shutdown the CH1 circulator(s).



The auxiliary Appliance circulator is also powered when the CH 1 circulator is manually enabled.

**DHW** - Press the **OK** button while the DHW icon is highlighted to manually power the DHW circulator(s) as in DHW demand.

Press the **OK** button again while the DHW icon is highlighted to shutdown the DHW circulator(s).



Manual Operation

The auxiliary Appliance circulator is also powered when the DHW circulator is manually enabled.

CH2 - Press the OK button while the CH2 icon is highlighted to manually power the CH2 circulator(s) as in CH demand.

Press the **OK** button again while the CH2 icon is highlighted to shutdown the CH2 circulator(s).

#### LIST OF STATUS LINE MESSAGES

Status Line Message	Description
Standby	Indicates that the Appliance is ready to respond when a demand is received.
CH Demand	A central heating call has been received.
DHW Demand	A domestic hot water call has been received.
CH / DHW Demand	Central heating and domestic hot water calls are being received simultaneously. Both calls are being satisfied simultaneously because domestic hot water priority has been disabled.
DHW Priority	Central heating and domestic hot water calls are being received simultaneously. Domestic hot water call is being satisfied first because it has priority over central heating calls.
Priority Timeout	Central heating and domestic hot water calls are being received simultaneously. The domestic hot water priority time limit has been exceeded. Priority will now switch back and forth between central heating and domestic hot water calls until one call is satisfied.
External Demand	An external modulation call has been received.
Slave Operation	The Prestige is a slave in a cascade system.
Manual Operation	The burner or circulators have manually been enabled in the Installer Menu.
CH Burner Delay	The burner will not fire until the call blocking time has elapsed.
DHW Burner Delay	The burner will not fire until the call blocking time has elapsed.
CH Setpoint Reached	The burner is not fired because the supply/system water temperature exceeds the setpoint. The central heating circulator continues to operate and the burner will fire again once the supply/system water temperature drops below the setpoint.
DHW Setpoint Reached	The burner is not fired because the supply/system water temperature exceeds the setpoint. The domestic circulator continues to operate and the burner will fire again once the supply/system water temperature drops below the setpoint.
CH Post Pump	The central heating circulator is running to remove heat from the Appliance at the completion of a call.
DHW Post Pump	The domestic hot water circulator is running to remove heat from the Appliance at the completion of a call.
Freeze Protection	Freeze protection will end once the supply/system water temperature is raised to 16°C.
Boiler Protection	The burner firing rate is being reduced because of an excessive difference between the appliance supply and return temperatures. The firing rate will begin increasing once the temperature difference is less than 25°C.
Lockout Description	The lockout which currently has the Appliance shut down is displayed.

#### **APPLIANCE CODES**


Appliance type	Model	Natural gas	Propane
Prestige Solo/Excellence (3-way valve)	24	A211	A212
	32	A221	A222
Prestige Solo	42	A131	A132
	50	A141	A142
	75	A151	A152
	100	A161	A162
	120	A171	A172
HeatMaster C	25	A411	A412
Heat Master TC	25	A421	A422
	35	A431	A432
	45	A441	A442
	70	A451	A452
	85	A461	A462
	120	A471	A472
WaterMaster	25	A621	A622
	35	A631	A632
	45	A641	A642
	70	A651	A652
	85	A661	A662
	120	A671	A672

#### **FACTORY SETTINGS AND RESET VALUES**

CH Parameters	Factory settings			EZ Setup reset	Installer reset
	Prestige Excel.	Prestige Solo	HeatMaster WaterMaster		
Heating Operation	Enabled	Enabled	Enabled		Enabled
Demand	Thermostat & Outd. Curve				
CH Maximum Capacity	100%	100%	100%		100%
Absolute Max CH Setpoint	87°C	87°C	87°C		87°C
CH1 Max Setpoint	82°C	82°C	82°C	82°C	82°C
CH1 Min Setpoint	27°C	27°C	27°C	27°C	27℃
Outdoor Curve Coldest Day	-12°C	-12°C	-12°C		-12°C
Outdoor Curve Warmest Day	18°C	18°C	18°C		18°C
CH2 Circuit	Enabled	Enabled	Enabled		Enabled
CH2 Max Setpoint	60°C	60°C	60°C	60°C	60°C
CH2 Min Setpoint	27°C	27°C	27°C	27°C	27°C
Warm Weather Shutdown	Off	Off	Off	Off	Off
Circulation pump permanent	Disabled	Disabled	Disabled		Disabled
CH Post Pump time	5 min	5 min	5 min		5 min
Freeze Protection	Enabled	Enabled	Enabled		Enabled
Frost Protection Setpoint	-30°C	-30°C	-30°C		-30°C
Parallel Shift Value	0°C	0°C	0°C		0°C
CH Call Blocking	2 min	2 min	2 min		2 min
DHW Parameters					
DHW Operation	Enabled	Enabled	Enabled	Enabled	Enabled
Demand	Sensor	Thermostat	Sensor	Thermostat	Thermostat
DHW Boiler Setpoint	75°C	75°C	75°C	75°C	75℃
DHW Setpoint	62°C	60°C	55°C	60°C	60°C
DHW on Differential	3℃	3℃	3℃		3°C
DHW Storage Adder	20°C	15°C	15°C		15℃
DHW Post Pump Time	1 min	1 min	2 min		1 min
DHW priority Timeout	Off	Off	Off	Off	Off
DHW priority	Enabled	Enabled	Enabled		Enabled
DHW Call Blocking	0 min	0 min	0 min		0 min
DHW to CH Call Blocking	1 min	1 min	1 min		1 min
Antilegionella Function	Enabled	Disabled	Enabled		Enabled


#### **ACVMAX MENU STRUCTURE**

Main Screen, Installer's Menu Disabled CH settings **CH&DHW Settings** Heating Settings Enabled **DHW Settings** Disabled Thermostat & Outd. curve **Reset All Settings** ➤ DHW Settings Heating operation Enabled Thermostat and Setpoint **Boiler Settings Manual Operation** DHW Operation Demand Constant & Outd. Curve Thermostat **Constant & Setpoint** Sensor Cascade Demand CH maximum capacity 0-10V modulation Signal CH maximum capacity DHW Boiler Setpoint Abs. max. CH setpoint -**DHW Boiler Setpoint** Abs. max. CH setpoint DHW Setpoint . CH1 max. setpoint DHW Setpoint CH1 max. setpoint DHW on Differential CH1 min. setpoint **DHW** on Differential CH1 min. setpoint Outd. Curve/ Coldest Day DHW Storage Adder Outd. Curve/ Coldest Day DHW Storage Adder Outd. Curve/ Warmest Day DHW Post Pump Time Outd. Curve/ Warmest Day DHW Post Pump Time Disabled Enabled **DHW Priority Timeout** DHW Priority Timeout CH2 circuit CH2 max. setpoint Enabled DHW Priority -CH2 max. setpoint Disabled CH2 min. setpoint DHW Call Blocking CH2 min. setpoint DHW Call Blocking Warm Weather Shutdown DHW to CH Call Blocking DHW to CH Call Blocking Warm Weather Shutdown -Disabled Enabled Enabled Antilegionella Function Circulation Pump Permanent, Disabled **CH Post Pump Time** CH Post Pump Time Disabled Freeze Protection Clicking on the bullet located in front of a menu title will take you to the function explanation. Enabled Frost Protection Setpoint Frost Protection Setpoint Parallel Shift Value Parallel Shift Value CH Call Blocking **CH Call Blocking** 



# THE INSTALLER'S HANDBOOK FOR HEATING SYSTEMS CONTROLLED WITH ACVMAX

# VOLUME 2 System Diagrams and ACVMax Setup



Prestige 24 - 32 Solo /Excellence Prestige 42 - 50 - 75 - 100 - 120 Solo HeatMaster 25 C HeatMaster 25 - 35 - 45 - 70 - 85 - 120 TC WaterMaster 25 - 35 - 45 - 70 - 85 - 120

Applicable to appliances manufactured from March 2016, equipped with at least software version (DSP) 3.05



#### **VOLUME 2 - SYSTEM DIAGRAMS AND ACVMAX SETUP**

USER'S GUIDE	2-3
General	2-3
Resistance of the temperature sensors	2-3
PRESTIGE SOLO/EXCEL (3-WAY VALVE)	2-4
Electrical Characteristics Prestige 24-32 Solo/Excellence	
Pumps (Prestige Solo/Excel (3-Way valve))	2-6
Preset Configuration 1	2-7
Two heating circuits, with two room thermostats and optional outdoor sensor, and with DHW circuit	2-7
Preset Configuration 2	2-8
Two heating circuits, with optional outdoor temperature sensor and room thermostats, and with DHW circu	it2-8
Preset Configuration 3	2-9
High and Low temperature heating circuits, with optional outdoor temperature sensor and room thermost. DHW circuit	
Preset Configuration 4	2-10
High and Low temperature heating circuits, with optional outdoor temperature sensor and room thermosta DHW circuit	
PRESTIGE SOLO (2 PUMPS)	2-11
Electrical Characteristics Prestige 42 - 50 - 75 Solo	
Electrical Characteristics Prestige 100-120 Solo	
Pumps (Prestige Solo)	
Preset Configuration 1	
High temperature heating circuit, possibly with optional outdoor temperature sensor and room thermostat circuit.	, without DHW
High temperature heating circuit, circulator pumps on return lines, possibly with optional outdoor temperat and room thermostat, and with DHW circuit.	
High temperature heating circuit, circulator pumps on supply lines, possibly with optional outdoor tempera and room thermostat, and with DHW circuit.	2-17
High temperature heating circuit, with additional load pump, possibly with optional outdoor temperature s room thermostat, and with DHW circuit	ensor and 2-18
High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature room thermostats, and with DHW circuit.	
High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature room thermostats, and with DHW circuit.	
Preset Configuration 4	
High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature room thermostats, and with DHW circuit.	
	2-21

Preset Configuration 32-23
High temperature heating circuits controlled through solenoid valves, with additional load pump, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit and DHW sensor2-23
High temperature heating circuits controlled through solenoid valves, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit and DHW sensor224
Preset Configuration 72-25
High and Low temperature heating circuits, with room control on Heating Circuit 1 (CH1) and possible second room control, possibly with optional outdoor temperature sensor and room thermostat2-25
High and Low temperature heating circuits, with room control on Heating Circuit 1 (CH1) and possible second room control, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit2-26
Preset Configuration 92-27
Preset Configuration 122-28
High and Low temperature heating circuit, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit
HEATMASTER AND WATERMASTER
Electrical Characteristics of HeatMaster® 120 TC, WaterMaster 1202-32
Pumps (HeatMaster)2-34
Pumps (WaterMaster)2-34
HEATMASTER 2-35
Preset Configuration 162-35
High temperature heating circuit, possibly with optional outdoor temperature sensor and room thermostat2-35
High temperature heating circuits, possibly with optional outdoor temperature sensor and room thermostats2-36
Preset Configuration 152-37
High and Low temperature heating circuits, possibly with optional outdoor temperature sensor and room thermostats 2-37
Preset Configuration 152-38
High and Low temperature heating circuits, possibly with optional outdoor temperature sensor and room thermostats

#### **GENERAL**

This volume contains information on the electrical connections, hydraulic connections and ACVMax controller set-up for Prestige 24-32 Solo/Excellence, Prestige 42-50-75-100-120 Solo, HeatMaster 25- 35-45-75-80-120 TC and 25 C and WaterMaster 25 - 35 - 45 - 70 - 85 - 120 that are required to operate the system configuration you have selected.

For simple configurations, the EZ setup function of the ACVMax can be used (refer to the Installation, Operation and Maintenance manual provided with the appliance).

For more complex systems, with additional pumps, several configurations have already been preset in the ACVMax controller to help you. Please refer to the table of contents on the previous page and to the following pages to see the predetermined configurations for the chosen appliance type.

For any system that is not mentioned in this manual, please contact your ACV representative.

#### RESISTANCE OF THE TEMPERATURE SENSORS

T° [°C]	RΩ	T° [°C]	RΩ
25	12000	70	2340
30	9800	75	1940
35	8050	80	1710
40	6650	85	1470
45	5520	90	1260
50	4610	95	1100
55	3860	100	950
60	3250		
65	2750		
	25 30 35 40 45 50 55 60	25 12000 30 9800 35 8050 40 6650 45 5520 50 4610 55 3860 60 3250	25 12000 70 30 9800 75 35 8050 80 40 6650 85 45 5520 90 50 4610 95 55 3860 100 60 3250

#### **ELECTRICAL CHARACTERISTICS PRESTIGE 24-32 SOLO/EXCELLENCE**

			PRESTIGE			
			Sc	olo	Excel	lence
Main Characteristics			24	32	24	32
Rated voltage		V~	230	230	230	230
Rated frequency		Hz	50	50	50	50
Electrical comprises	Max.	W	89	94	89	94
Electrical consumption	Min.	W	15	15	15	15
Electrical consumption at 30% load		W	17	17	17	17
Electrical consumption in standby		W	5	5	5	5
Rated current (Fuse)		Α	16	16	16	16
Class		IP	X4D	X4D	X4D	X4D

DDECTICE



The power cord may only be replaced by a genuine ACV spare part, P/N 257F1180.

#### Key

- 230 V power supply plug
- Ground
- ON/OFF master switch
- Gas valve rectified
- Burner power supply
- Terminal block for optional items



: Alarm (ERR)



230 VAC OUTPUT!

: CH circuit circulator pump (CH)



: DHW circuit circulator pump (DHW)

7. Optional terminal block for optional items:



: Pump (P3 and P4 terminals)



: Flame terminal (versatile connection according to configuration)


- Modulating pump PWM
- 3-way valve stepper motor
- 10. Burner PWM plug
- NTC5 flue gas temperature sensor
- 12. NTC2 return sensor
- 13. NTC1 supply sensor
- 14. NTC - Low temperature circuit

### For low temp circuit operation, black wires from X3, terminals 1 & 6 must be routed to X20, terminals 3 & 4.

230 VAC OUTPUT!

- 15. High limit switch
- 16. Low water pressure sensor
- 17. PCB (Display)
- 18. ACVMax programmation plug
- A & B Modbus (option)
- NTC3 DHW sensor (option for Prestige 24 32 Solo))
- NTC4 outdoor temperature sensor (option)
- 22. Room thermostat 1 (option)
- 23. 0-10 Volt (option)
- Room thermostat 2 (option) 24.
- Connection for interface control unit 25.
- Ignition and ionization cable
- 5AT slow-blow fuse (3x) for internal and optional circuits\*
- \* 5AT slow-blow fuse (2x) for internal circuits and connection of CH, DHW and Flame output + 5AT slow-blow fuse (1x) for connection of Alarm, P3 and P4 (connector P14)
- 2 spare 5AT slow-blow fuses are located on the back side of the electrical box, for fuse replacement, if required.





#### **PUMPS (PRESTIGE SOLO/EXCEL (3-WAY VALVE))**

The pump configurator system is based on the demands of the hydraulic system that you design. In the table below, you will find the 4 configurations that have been preset in the ACVMax controller for the Prestige 24-32 Solo/Excellence (identified as "Solo/Excel. (3-way valve)" in the Prestige Model selection menu), based on different hydraulic schemes that can be used.

The table shows which relays are activated under which condition.


The names in the table refer to the demand done by CH1 by CH2 or DHW respectively, the demand to open/close the Motor of a mixing valve or reflect the activation of the alarm (error) or Flame output relay. In the following pages, you will find these diagrams with a configuration number that corresponds to the setting in the display.

Config. No	Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 FL
1	Error	CH2	CH1		CH1/CH2/ DHW	Flame
2	Error	CH2	CH1	CH1/CH2	CH1/CH2/ DHW	Flame
3	Error	CH2	CH1	Mix open	CH1/CH2/ DHW	Mix close
4	Error	CH1/CH2	CH1	Mix open	CH1/CH2/ DHW	Mix close


**Pump Configuration 1** 

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1		CH1/CH2/ DHW	Flame

Two heating circuits, with two room thermostats and optional outdoor sensor, and with DHW circuit.









Main Screen	Sub- screen	item	Sub-item	Required selection
	ייים אייים	Model		Prestige 3WV (Pre-set)
	Q ·	Pump Settings	Preset Pump Config	Solo/Excellence 1
		Heating Operation		Enabled ( )
	<b></b>	CH2 Circuit		Enabled
	₹©\$	Demand		Thermostat and Outd. curve
	<b>△</b>	DHW Operation		Enabled (♣)
	<b>*</b> O* -	Demand		Sensor

**Pump Configuration 2** 

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1	CH1/CH2	CH1/CH2/ DHW	Flame

Two heating circuits, with optional outdoor temperature sensor and room thermostats, and with DHW circuit.






Main Screen	Sub- screen	item	Sub-item	Required selection
	ر الم	Model		Prestige 3WV (Pre-set)
		Pump Settings	Preset Pump Config	Solo/Excellence 2
		Heating Operation		Enabled ( )
(114)		CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
	<b>∞→</b>	DHW Operation		Enabled ( 📥 )
	<b>₽</b>	Demand		Sensor


#### **Pump Configuration 3**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1	Mix open	CH1/CH2/ DHW	Mix close

High and Low temperature heating circuits, with optional outdoor temperature sensor and room thermostats, and with DHW circuit.



- Essential recommendations for the correct operation of the system
  - Low temperature sensor is not shown here, but make sure to install one to control the circuit (using the additional wiring made available in the optional wiring kit).
  - Low temperature cut-out thermostat is not shown here, but make sure to install one to
    protect the low temperature circuit (to be connected to X20 terminal, ref. 14 on Prestige
    24-32 Solo/Excellence wiring diagram).




<sup>\*</sup>The room thermostat 1 always controls the low temperature system.


Main Screen	Sub- screen	item	Sub-item	Required selection
	ALLY.	Model		Prestige 3WV (Pre-set)
		Pump Settings	Preset Pump Config	Solo/Excellence 3
		Heating Operation		Enabled (##)
	O <b>III</b>	CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
	<i>₹</i>	DHW Operation		Enabled (
	<b>W</b>	Demand		Sensor

#### **Pump Configuration 4**


Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH1/CH2	CH1	Mix open	CH1/CH2/ DHW	Mix close

High and Low temperature heating circuits, with optional outdoor temperature sensor and room thermostats, and with DHW circuit.





- Low temperature sensor is not shown here, but make sure to install one to control the circuit (using the additional wiring made available in the optional wiring kit).
- Low temperature cut-out thermostat is not shown here, but make sure to install one to protect the low temperature circuit (to be connected to X20 terminal, ref. 14 on Prestige 24-32 Solo/Excellence wiring diagram).



<sup>\*</sup>The room thermostat 1 always controls the low temperature system.

Main Screen	Sub- screen	item	Sub-item	Required selection
	لما المالي	Model		Prestige 3WV (Pre-set)
		Pump Settings	Preset Pump Config	Solo/Excellence 4
Ö (************************************	*****	Heating Operation		Enabled ( )
		CH2 Circuit		Enabled
	<b>₩</b>	Demand		Thermostat and Outd. curve
	<b>₩→</b>	DHW Operation		Enabled (
	<b>₩</b>	Demand		Sensor

#### **ELECTRICAL CHARACTERISTICS PRESTIGE 42 - 50 - 75 SOLO**

			PRESTIGE SOLO	
Main Characteristics		42	50	75
Rated voltage	V~	230	230	230
Rated frequency	Hz	50	50	50
Electrical consumption	W	78	78	126
Class	IP	X4D	X4D	X4D

#### **ELECTRICAL CHARACTERISTICS PRESTIGE 100-120 SOLO**

		PRESTIGE SOLO		
Main Characteristics		100	120	
Rated voltage	V~	230	230	
Rated frequency	Hz	50	50	
Electrical consumption	W	150	180	
Class	IP	X4D	X4D	

#### Key

- 1. 230 V power supply
- Ground
- . ON/OFF master switch
- 4. Gas valve (rectified for Prestige 42 50 75 Solo)
- Burner power supply
- 6. Terminal block for optional items



: Alarm (ERR terminal)



: Flame terminal (versatile connection according to configuration)

230 VAC OUTPUT!



: CH circuit circulator pump (CH terminal)



: DHW circuit circulator pump (DHW terminal)

7. Optional terminal block for optional items:



: Pump (P3 and P4 terminals)





230 VAC OUTPUT!

- 3. Burner PWM plug
- 9. NTC5 flue gas temperature sensor
- NTC2 return sensor
- 11. NTC1 supply sensor
- 12. Gas pressure switch
- 13. NTC Low temperature circuit

#### For low temp circuit operation, black wires from X3, terminals 1 & 6 must be routed to X20, terminals 3 & 4.

- 14. High limit switch
- 15. Low water pressure sensor
- 16. PCB (Display)
- 17. ACVMax programmation plug
- 18. Cascade harness connection terminal
- 19. A & B Modbus (option)
- 20. NTC3 DHW sensor (option)
- 21. NTC4 outdoor temperature sensor (option)
- 22. Room thermostat 1 (option)
- 23. 0-10 Volt (option)
- 24. Cascade temp. sensor (option)
- 25. Room thermostat 2 (option)
- 26. Ignition and ionization cable
- 27. Connection for Interface Control Unit (option)
- 28. 5AT slow-blow fuse (3x) for internal and optional circuits\*
- \* 5AT slow-blow fuse (2x) for internal circuits and connection of CH, DHW and Flame output + 5AT slow-blow fuse (1x) for connection of Alarm. P3 and P4 (connector P14).
- 2 spare 5AT slow-blow fuses are located on the back side of the electrical box, for fuse replacement, if required.





#### **PUMPS (PRESTIGE SOLO)**


The pump configurator system is based on the demands of the hydraulic system that you design. In the table below, you will find the 13 configurations that have been preset in the ACVMax controller for the Prestige 42-50-75-100-120 Solo (identified as "Prestige Solo" in the Prestige Model selection menu), based on different hydraulic schemes that can be used.

The table shows which relays are activated under which condition.

The names in the table refer to the demand done by CH1 by CH2 or DHW respectively, the demand to open close the Motor of a mixing valve or reflect the activation of the alarm (error) or Flame output relay.

In the following pages, you will find these diagrams with a configuration number that corresponds to the setting in the display.

Config. No	Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 FL
1	Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame
2	Error	CH1	CH1/CH2/ DHW	DHW	CH1/CH2/ DHW	Flame
3	Error		CH1/CH2	DHW	CH1/CH2	Flame
4	Error	CH2	CH1/CH2	DHW	CH1	Flame
5	Error	CH2	CH1	DHW	CH1/CH2/ DHW	Flame
6	Error		CH1	DHW	CH1	Flame
7	Error	CH1/CH2	Mix open	DHW	CH1 low	Mix close
8	Error	CH2	CH1/CH2	CH1/CH2/ DHW	CH1	Flame
9	Error	CH/DHW	Mix open	DHW	CH1 low	Mix close
10	Mix open	CH1/CH2	CH1/CH2	DHW	CH1 low	Mix close
11	Mix open	CH1/CH2	CH2	DHW	CH1 low	Mix close
12	Mix open	CH1/CH2/ DHW	CH2	DHW	CH1 low	Mix close
13	Error	CH1/CH2	CH2	Mix open	CH1 low	Mix close







**General Remark** 

Cascade Systems"


Preset configurations 2 and 5 are for Cascade systems. Please refer to "VOLUME 3 -


**Pump Configuration 1** 

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame

High temperature heating circuit, possibly with optional outdoor temperature sensor and room thermostat, without DHW circuit.









Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 1
Ö	11111	Heating Operation		Enabled ( )
	© IIII	Demand		Thermostat and Outd. curve
		DHW Operation		Disabled ( )

High temperature heating circuit, circulator pumps on return lines, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit.



#### **Pump Configuration 1**

			-		
Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 FL
Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame




Terminal name --> Connected to

**Electrical board terminals** 


Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 1
Ö		Heating Operation		Enabled ( Enabled (
Tar.		CH2 Circuit		Disabled
	***	Demand		Thermostat and Outd. curve
	<b>*</b>	DHW Operation		Enabled (
		Demand		Sensor

High temperature heating circuit, circulator pumps on supply lines, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit.




#### **Pump Configuration 1**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame




Main Screen	Sub- screen	item	Sub-item	Required selection
	aria 🖟	Model		Prestige Solo (Pre-Set)
	₹©r	Pump Settings	Preset Pump Config	Config 1
Ö		Heating Operation		Enabled (###)
'AM'		CH2 Circuit		Disabled
		Demand		Thermostat and Outd. curve
	<b>₹</b>	DHW Operation		Enabled ( )
	<b>#</b>	Demand		Sensor

High temperature heating circuit, with additional load pump, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit.




#### Pump Configuration 1

_						
	Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 FL
	Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame




Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 1
Ö		Heating Operation		Enabled ( )
ได้เก็		CH2 Circuit		Disabled
		Demand		Thermostat and Outd. curve
	<b>*</b>	DHW Operation		Enabled (
		Demand		Sensor

High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit.




#### **Pump Configuration 1**

Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 Flame
Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame




Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 1
Ö		Heating Operation		Enabled ( )
ኒ <sub>ፙ</sub> ና		CH2 Circuit		Enabled
	<b>%</b>	Demand		Thermostat and Outd. curve
	<b>₽</b>	DHW Operation		Enabled (♣)
	<b>X</b>	Demand		Sensor

High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit.



#### **Pump Configuration 1**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1/CH2/ DHW	DHW	CH1	Flame




Main Screen	Sub- screen	item	Sub-item	Required selection
	AVID DE	Model		Prestige Solo (Pre-set)
		Pump Settings	Preset Pump Config	Config 1
Ö		Heating Operation		Enabled ( )
יאאי		CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
	<b>*</b>	DHW Operation		Enabled ( )
		Demand		Sensor


**Pump Configuration 4** 


Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1/CH2	DHW	CH1	

High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit.











Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 4
	<b>#</b>	Heating Operation		Enabled (##)
<b>7</b> M		CH2 Circuit		Ensabled
		Demand		Thermostat and Outd. curve
		DHW Operation		Enabled (
		Demand		Sensor

High temperature heating circuits, with additional load pump, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit.



#### **Pump Configuration 4**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH2	CH1/CH2	DHW	CH1	Flame





Main Screen	Sub- screen	item	Sub-item	Required selection
	ريي	Model		Prestige Solo (Pre-Set)
	<b>©</b>	Pump Settings	Preset Pump Config	Config 4
	<b>;</b>	Heating Operation		Enabled ( )
(AV)		CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
	<b>*</b>	DHW Operation		Enabled (
		Demand		Sensor

**Pump Configuration 3** 

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error		CH1/CH2	DHW	CH1/CH2	Flame


High temperature heating circuits controlled through solenoid valves, with additional load pump, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit and DHW sensor.






Main Screen	Sub- screen	item	Sub-item	Required selection
	Series Constitution	Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 3
	<b>;;;;</b> ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;	Heating Operation		Enabled (##)
7 <sub>10</sub> 1		CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
		DHW Operation		Enabled ( )
		Demand		Sensor

High temperature heating circuits controlled through solenoid valves, possibly with optional outdoor temperature sensor and room thermostats, and with DHW circuit and DHW sensor.



#### **Pump Configuration 3**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error		CH1/CH2	DHW	CH1/CH2	Flame




Main Screen	Sub- screen	item	Sub-item	Required selection
	יאואי אייני	Model		Prestige Solo (Pre-Set)
	<b>©</b>	Pump Settings	Preset Pump Config	Config 3
Ö		Heating Operation		Enabled ( <b>)</b>
ሳ <sub>ስ</sub>		Demand		Thermostat and Outd. curve
		CH2 Circuit		Enabled
	<b>*</b>	DHW Operation		Enabled (♣)
	<b>##</b>	Demand		Sensor

**Pump Configuration 7** 


Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH1/CH2	Mix open	DHW	CH1 low	Mix close

High and Low temperature heating circuits, with room control on Heating Circuit 1 (CH1) and possible second room control, possibly with optional outdoor temperature sensor and room thermostat.



#### Essential recommendations for the correct operation of the system


- Low temperature sensor is not shown here, but make sure to install one to control the circuit (using the additional wiring made available in the optional wiring kit).
- Low temperature cut-out thermostat is not shown here, but make sure to install one to protect the low temperature circuit (to be connected to X20 terminal, ref. 13 on Prestige 42-50-75-100-120 Solo wiring diagrams).



<sup>\*</sup> The room thermostat 1 always controls the low temperature system.


Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 7
		Heating Operation		Enabled (##)
<b>%</b>		Demand		Thermostat and Outd. curve
		CH2 Circuit		Enabled
	<b>\$</b>	DHW Operation		Enabled ( )
		Demand		Sensor


High and Low temperature heating circuits, with room control on Heating Circuit 1 (CH1) and possible second room control, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit.



#### **Pump Configuration 7**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Error	CH1/CH2	Mix open	DHW	CH1 low	Mix close





<sup>\*</sup> The room thermostat 1 always controls the low temperature system.

Main Screen	Sub- screen	item	Sub-item	Required selection
\$ <sup>6</sup> 63		Model		Prestige Solo (Pre-Set)
		Pump Settings	Preset Pump Config	Config 7
		Heating Operation		Enabled ( )
		Demand		Thermostat and Outd.
		CH2 Circuit		Enabled
	<b>*</b>	DHW Operation		Enabled (
		Demand		Sensor





Do not use this configuration. It is not activated yet.


**Pump Configuration 12** 

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	FL
Mix open	CH1/CH2/ DHW	CH2	DHW	CH1 low	Mix close

High and Low temperature heating circuit, possibly with optional outdoor temperature sensor and room thermostat, and with DHW circuit.







<sup>\*</sup> The room thermostat 1 always controls the low temperature system.

Main Screen	Sub- screen	item	Sub-item	Required selection
	STIZ	Model		Prestige Solo (Pre-Set)
	\$Q\$`	Pump Settings	Preset Pump Config	Config 12
	<b>©</b>	Heating Operation		Enabled ( <b>)</b>
		Demand		Thermostat and Outd.
		CH2 Circuit		Enabled
	<b>*</b>	DHW Operation		Enabled ( 📥 )
		Demand		Sensor

## ELECTRICAL CHARACTERISTICS HEATMASTER® 25-35-45 TC, HEATMASTER® 25 C AND WATERMASTER 25 - 35 - 45

HeatMaster TC	/ WaterMaster
---------------	---------------

Main Characteristics			25	35	45
Rated voltage		V~	230	230	230
Rated frequency		Hz	50	50	50
	Max.	W	95	111	126
Electrical consumption	Min.	W	19	30	40
Electrical consumption at 30% load		W	24	34	45
Electrical consumption in standby		W	3	3	3
Rated current (Fuse)		Α	16	16	16
Class			IP 20	IP 20	IP 20

#### HeatMaster 25C

#### **Main Characteristics**

Rated voltage		V~	230
Rated frequency		Hz	50
	Max.	W	95
Electrical consumption	Min.	W	19
Electrical consumption at 30% load		W	24
Electrical consumption in standby		W	3
Rated current (Fuse)		Α	16
Class			IP 20

#### Key

- 1. 230 V power supply
- 2. Ground
- ON/OFF master switch
- 4. Gas valve rectified
- 5. Burner power supply
- 6. Terminal block for optional items



: Alarm (ERR)



230 VAC OUTPUT!



: DHW circuit circulator pump (DHW)

7. Terminal block for optional items:



: Pump (P3 and P4 terminals)



: Flame terminal (versatile connection according to configuration)





230 VAC OUTPUT!


- Modulating pump PWM
- 9. Burner PWM plug
- 10. NTC5 flue gas temperature sensor
- 11. NTC2 return sensor
- 12. NTC1 supply sensor
- 13. NTC Low temperature circuit

## For low temp circuit operation, black wires from X3, terminals 1 & 6 must be routed to X20, terminals 3 & 4.

- 14. High limit switch
- 15. Low water pressure sensor
- 16. PCB (Display)
- 17. ACVMax programmation plug
- 18. A & B Modbus (option)
- NTC3 DHW sensor
- 20. NTC4 outdoor temperature sensor (option)
- 21. Room thermostat 1 (option)
- 22. 0-10 Volt (option)
- 23. Room thermostat 2 (option)
- 24. Connection for interface control unit
- 25. Ignition and ionization cable
- 26. 5AT slow-blow fuse (3x) for internal and optional circuits\*
- \* 5AT slow-blow fuse (2x) for internal circuits and connection of CH, DHW and Flame output + 5AT slow-blow fuse (1x) for connection of Alarm. P3 and P4 (connector P14)







#### ELECTRICAL CHARACTERISTICS OF HEATMASTER® 70-85 TC, WATERMASTER 70 - 85

			Heat Master TC	/ WaterMaster
Main Characteristics			70	85
Rated voltage		V~	230	230
Rated frequency		Hz	50	50
Electrical concumption	Max.	W	210	266
Electrical consumption	Min.	W	50	46
Electrical consumption at 30% load		W	55	51
Electrical consumption in standby		W	3	3
Rated current (Fuse)		Α	16	16
Class			IP 20	IP 20

#### **ELECTRICAL CHARACTERISTICS OF HEATMASTER® 120 TC, WATERMASTER 120**

			HeatMaster TC / WaterMaster
Main Characteristics			120
Rated voltage		V~	230
Rated frequency		Hz	50
Floatrical consumption	Max.	W	327
Electrical consumption -	Min.	W	70
Electrical consumption at 30% load		W	74
Electrical consumption in standby		W	4
Rated current (Fuse)		Α	16
Class			IP 20

#### Key

- 1. 230 V power supply
- Ground
- ON/OFF master switch
- Gas valve
- Burner power supply
- Terminal block for optional items



: Alarm (ERR terminal)



230 VAC OUTPUT!



: DHW circuit circulator pump (DHW terminal)

7. Terminal block for optional items:



: Pump (P3 and P4 terminals)




: Flame terminal (versatile connection according to configuration) 230 VAC OUTPUT!



- Burner PWM plug
- NTC5 flue gas temperature sensor
- NTC2 return sensor
- 11. NTC1 supply sensor
- Gas pressure switch 12.
- 13. NTC Low temperature circuit

## For low temp circuit operation, black wires from X3, terminals 1 & 6 must be routed to X20, terminals 3 & 4.

- High limit switch
- 15. Low water pressure sensor
- 16. PCB (Display)
- ACVMax programmation plug
- A & B Modbus (option) 18.
- 19. NTC3 DHW sensor
- 20. NTC4 outdoor temperature sensor (option)
- 21. Room thermostat 1 (option)
- 0-10 Volt (option) 22.
- Room thermostat 2 (option) 23.
- Ignition and ionization cable
- Connection for Interface Control Unit (option)
- 5AT slow-blow fuse (3x) for internal and optional circuits\*
- Modulating pump PWM
- \* 5AT slow-blow fuse (2x) for internal circuits and connection of CH, DHW and Flame output + 5AT slow-blow fuse (1x) for connection of Alarm, P3 and P4 (connector P14).
- 2 spare 5AT slow-blow fuses are located on the back side of the electrical box, for fuse replacement, if required.



#### **PUMPS (HEATMASTER)**

The pump configurator system is based on the demands of the hydraulic system that you design. In the table below, you will find the 4 configurations that have been preset in the ACVMax controller for the HeatMaster 25-35-45-70-85-120 TC and HeatMaster 25 C, based on different hydraulic schemes that can be used.

The table shows which relays are activated under which condition.

The names in the table refer to the demand done by CH1 by CH2 or DHW respectively, the demand to open close the Motor of a mixing valve or reflect the activation of the alarm (error) or Flame output relay.

In the following pages, you will find these diagrams with a configuration number that corresponds to the setting in the display.

Config. No	Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 FL
5	Error/Flame	CH2	CH1	DHW	CH1/CH2/ DHW	Flame
14	Error/Flame	Mix open	CH1/CH2	CH1	CH1/CH2/ DHW	Mix close
15	Mix open	CH2	CH1/CH2	CH1	CH1/CH2/ DHW	Mix close
16	Error/Flame	CH2	CH1/CH2	CH1	CH1/CH2/ DHW	Flame

#### **PUMPS (WATERMASTER)**

The pump configurator system is based on the demands of the hydraulic system that you design. In the table below, you will find the 4 configurations that have been preset in the ACVMax controller for the WaterMaster 25-35-45-70-85-120, BUT only preset Config N° 5 is currently active for the appliance.

The table shows which relays are activated under which condition.


No specific Hydraulic diagram is currently available for the WaterMaster.


Config. No	Flex 4 ERR	Flex 6 P4	Flex 3 P3	Flex 2 DHW	Flex 1 CH	Flex 5 FL
5	Error/Flame	CH2	CH1	DHW	CH1/CH2/ DHW	Flame
14						
15			Not a	ictive		
16						

Pump Configuration 16

Config.	Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
	ERR	P4	P3	DHW	CH	FL
16	Error/Flame	CH2	CH1/CH2	CH1	CH1/CH2/ DHW	Flame

High temperature heating circuit, possibly with optional outdoor temperature sensor and room thermostat.







Main Screen	Sub- screen	item	Sub-item	Required selection
	יין איזא	Model		HeatMaster (Pre-Set)
	Ø.	Pump Settings	Preset Pump Config	Config 16
	<b>_   </b>	Heating Operation		Enabled ( )
		Demand		Thermostat and Outd. curve
	407	CH2 Circuit		Disabled
	<b>*</b>	DHW Operation		Enabled (
		Demand		Sensor


Pump Configuration 16

Config.	Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
	ERR	P4	P3	DHW	CH	FL
16	Error/Flame	CH2	CH1/CH2	CH1	CH1/CH2/ DHW	Flame

High temperature heating circuits, possibly with optional outdoor temperature sensor and room thermostats.








ACVMax interface settings using the Installer menu (Installer code needed, see <u>"Installer Code"</u>):


Main Screen	Sub- screen	item	Sub-item	Required selection
	ر المالي	Model		HeatMaster (Pre-Set)
		Pump Settings	Preset Pump Config	Config16
		Heating Operation		Enabled ( )
		Demand		Thermostat and Outd. curve
		CH2 Circuit		Enabled
		DHW Operation		Enabled (♣)
	₽ŲP	Demand		Sensor

Pump Configuration 15

Config.	Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
	ERR	P4	P3	DHW	CH	FL
15	Mix open	CH2	CH1/CH2	CH1	CH1/CH2/ DHW	Mix close

High and Low temperature heating circuits, possibly with optional outdoor temperature sensor and room thermostats.





ACVMax interface settings using the Installer menu (Installer code needed, see <u>"Installer Code"</u>):


. Optional room thermostat 2


		,		
Main Screen	Sub- screen	item	Sub-item	Required selection
		Model	HeatMaster (Pre-Set)	
		Pump Settings	Preset Pump Config	Config15
<b>**</b>		Heating Operation	Enabled (##)	
		Demand		Thermostat and Outd. curve
		CH2 Circuit		Enabled
	<b>*</b>	DHW Operation		Enabled ( )
		Demand		Sensor


Pump Configuration 15

Config.	Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
	ERR	P4	P3	DHW	CH	FL
15	Mix open	CH2	CH1/CH2	CH1	CH1/CH2/ DHW	Mix close

High and Low temperature heating circuits, possibly with optional outdoor temperature sensor and room thermostats.








ACVMax interface settings using the Installer menu (Installer code needed, see "Installer Code"):

Main Screen	Sub- screen	item	Sub-item	Required selection
		Model		HeatMaster (Pre-Set)
		Pump Settings	Preset Pump Config	Config15
	<b>, 111</b>	Heating Operation		Enabled ( )
		Demand		Thermostat and Outd. curve
	407	CH2 Circuit		Enabled
	<b>*</b>	DHW Operation		Enabled ( )
		Demand		Sensor

## THE INSTALLER'S HANDBOOK FOR HEATING SYSTEMS CONTROLLED WITH ACVMAX



# **VOLUME 3 Cascade Systems**

Prestige 42 - 50 - 75 - 100 - 120 Solo

Applicable to appliances manufactured from March 2016, equipped with at least software version (DSP) 3.05



#### **VOLUME 3 - CASCADE SYSTEMS**

GENERAL INFORMATION	3-3
User's Guide	
Operating Principles of an ACVMax-Controlled Cascade	3-3
MENUS AND SCREENS DESCRIPTION	3-4
Cascade Menu ( )> Cascade Information ( )	3-4
Cascade Menu ( Cascade Settings ( )	3-5
Cascade ( Cascade Autodetection ( )	3-9
Structure of the ACVMax cascade menu	3-10
INSTALLATION OF THE CASCADE BOILERS	3-11
General process for cascade installation	3-11
INSTALLATION AND CONFIGURATION OF CASCADE SYSTEMS	3-12
Assembling the Cascade Mounting rack	
Hydraulic connections of Cascade Systems	3-14
Chimney connections of Cascade Systems	
Cascade system connection (4-boiler Cascade)	3-18
Cascade start-up process	3-19
Accessing the Cascade Autodetection page	3-19
Preset Configuration 2	
3-boiler cascade configuration, high temperature, with DHW circuit	
3-boiler cascade configuration, high temperature, with DHW circuit	3-22
Preset Configuration 5	
3-boiler cascade configuration, with two high temperature heating circuits and DHW circuit	3-24

#### **USER'S GUIDE**

This section contains information on the cascade systems, i.e. a description of the ACVMax menus and screens, as well as how to connect several boilers in a cascade (hydraulics, chimney and electrical connections). It also presents several hydraulic diagrams and the ACVMax controller set-up for cascade systems (Prestige 42-50-75-100-120 Solo boilers).

The connections are made using specific kits that are detailed hereafter.

This manual explains the complete installation of a cascade using the rack mounting kit. However, a cascade can also be built using a Prestige box. For more information, please contact to your ACV representative.

For any cascade system that is not mentioned in this manual, please contact your ACV representative.

#### OPERATING PRINCIPLES OF AN ACVMAX-CONTROLLED CASCADE

Prestige Solo (2 pumps) boilers can be setup in a cascade configuration (max. 4 boilers) that is controlled by the ACVMax Boiler Control System.

The boilers can operate together without the need for an external cascade controller. One Prestige will be selected as the Master and will be wired to accept all the low voltage control signals and all the system pumps. The Master appliance organizes the distribution of the heat demands over the appliances in the cascade

The other Prestige boilers will be designated as Slaves and will only have a communication cable connecting them to the other boilers in the Cascade System.

The CH heat demands follow the same logic as the heat demands in a single appliance: the target setpoint at first start-up is calculated, following a temperature rise of 4K/min. The start-up sequence calculates the desired capacity according to the target setpoint.

The first appliance starts and as soon as it reaches twice the minimum capacity of the appliance, the second appliance will be started when the stage delay has expired. Both appliances are then running at minimum capacity.

The capacity increase continues following the rise of the calculated target setpoint. The third appliance will be started as soon as the two appliances have reached 3 times the minimum capacity. The cascading strategy is to have as many running appliances as possible.

The control parameters to determine the control speed of the cascade is derived from the individual appliance capacity parameter.

As soon as the System temperature comes in reach of the target system temperature the capacity increase will stop and the normal temperature control takes over.


Be aware that in a cascade the temperature control is done on the system temperature and NOT on the local temperature. That means that the local temperature can be easily 5 to 7 K higher than the system temperature depending on the position of the system sensor.


The local temperature is limited by the absolute max. local CH flow temperature.

The Cascade control works as a power control on the local appliances. The system temperature is the parameter to regulate and the local temperatures are of no avail, they are only used to limit the local power in case the max. temperature is reached.


#### Additional characteristics:

- The Cascade function allows up to four identical Prestige boilers to operate together in a single heating system.
- Parallel Modulation fires as many boilers as possible to maximize system efficiency.
- The Auto rotation function rotates the lead boiler every time a call for heat is received when a Thermostat
  option is chosen in CH Demand or every 24 hours when a Constant option is chosen in CH Demand.






**Cascade Info** provides real time operating information of the Cascade System. Each line contains an information item followed by its current value.



Cascade Info provides the following information item:


- Cascade Role Displays the current role of the Prestige in the Cascade System. Cascade Role will be one of the following:
  - **Master** Indicates this Prestige is the Master boiler in the Cascade System.
  - **Slave** Indicates this Prestige is a Slave boiler in the Cascade System.
  - **Standalone** Indicates this Prestige is not part of a Cascade System.
- System Temp See description below.
- Active boilers Displays the current number of boilers fired in the Cascade System
- Total Boilers Displays the total number of boilers in the Cascade System.
- Cascade Firing Rate Displays the current firing rate of the entire Cascade System.




**System Temp.** - Displays the current system temperature reading on the Master boiler. If the system sensor is not wired in to the Master boiler, the Master boiler supply temperature is displayed. It has a logging function which records one sample every 12 minutes to produce a graph of the last 24 hours.

Select **System Temp.** in Cascade Info. then press the **OK** button to view the graph.

MENUS AND SCREENS DESCRIPTION EN



"Installer Code"



CH / DHW Boilers

Enabled

**P** 

Auto Rotation

CH Prop. Gain

The Cascade Settings menu contains settings related to cascade operation. Each line contains a Cascade Setting followed by its current value. Six Cascade Settings are displayed on the screen at one time.

Press the **UP** or **DOWN** buttons to scroll through additional Cascade Settings.

Cascade Setting changes must be made on the cascade Master. Cascade autodetection must be performed after making any changes to a cascade Setting before the change will take effect.

> Stage Delay sets the time delay before enabling or disabling a boiler in the Cascade System. The Stage Delay begins once the Master boiler determines that a boiler must be enabled to reach the setpoint or when the Master boiler determines a boiler should be disabled because of a decreasing load.

Press the **LEFT** or **RIGHT** buttons to adjust the time then press the **OK** button to store the setting.

Adjusting the Stage Delay will have the following effects:

#### · Increasing Stage delay

- Reaching the setpoint could take longer due to a longer delay between enabling boilers.
- Overshooting the setpoint could occur due to boilers staying on longer before being disabled.

#### Decreasing Stage delay

- Overshooting the setpoint could occur due to boilers being enabled quicker.
- Boilers will be disabled quicker, possibly increasing boiler cycling and decreasing runtimes.

Minimum Firing Rate is the minimum firing rate of a single boiler in the Cascade System. The Master boiler uses this setting to determine when boilers can be enabled and disabled.

Setting the Minimum Firing Rate below the recommended minimum will result in boilers being enabled too quickly which may cause sharp increases in temperature from the Cascade System.


Setting the Minimum Firing Rate above the recommended minimum will delay the enabling of boilers which may lower the system efficiency.

Press the **LEFT** or **RIGHT** buttons to adjust the Minimum Firing Rate then press the **OK** button to store the setting.

Default: 25%

₽

 $\mathbf{r}$ Only make changes after being instructed to do so by ACV as changing of this value may cause instability in the appliance cascade control.



**Maximum Firing Rate** is the maximum capacity of a single boiler in the Cascade System.

Press the **LEFT** or **RIGHT** buttons to adjust the Maximum Firing Rate then press the **OK** button to store the setting.

This value, expressed in kW, will correspond to the current appliance range.

Default: according to the boilers

Stable cascade operation requires that all boilers in a cascade System be the same size. Mixing boiler sizes in a cascade System could lead to temperature fluctuations and erratic cascade operation.

The CH or DHW Boilers setting specifies how many boilers in a Split Cascade System will respond to a domestic hot water call.

The CH or DHW Boilers always include the Master boiler. The remaining boilers will only respond to central heating calls. This allows the Cascade System to satisfy both central heating and domestic hot water calls at the same time. At the completion of a domestic hot water call, the CH or DHW Boilers will again be available to respond to central heating calls.

Press the **LEFT** or **RIGHT** buttons to adjust the CH or DHW Boilers setting then press the **OK** button to store the setting




The maximum number of boilers in a cascade is 4. Therefore, do not select a higher number than 3 in this menu as one should never adjust to the same number as he has appliances in the cascade. This would override the Split of the system. Failure to comply may result in faults in the cascade operation.

Through the **Auto Rotation** function, the number of burning hours is equalized over all appliances.

When the function is **Enabled**, the appliances will all run an equal amount of time. This helps balancing wear over the appliances.

When the function is **Disabled**, there is no levelling of burning hours and the first appliances in the sequence will run more than the last one in the sequence.

Press the **UP** or **DOWN** buttons to enable or disable the function, then on **OK** to validate your selection.



**CH Proportional Gain** allows the cascade response to be adjusted for a central heating call. CH Proportional Gain has the greatest influence when the system temperature is far away from the setpoint.

Press the **LEFT** or **RIGHT** buttons to adjust the CH Proportional Gain then press the **OK** button to store the setting.

#### · Increase CH Proportional Gain

- The Cascade System will reach setpoint faster, but overshooting the setpoint may occur.
- To reach the setpoint faster, increase the CH Proportional Gain value by 2. Perform Cascade Autodetection and initiate a central heating call. Observe the cascade response and make further adjustments if necessary..

#### · Decrease CH Proportional Gain

- The Cascade System will take longer to reach the setpoint, but setpoint overshooting is minimized.
- If the setpoint is reached too quickly, decrease the CH Proportional Gain value by 2. Perform Cascade Autodetection and initiate a central heating call. Observe the cascade response and make further adjustments if necessary

Default: 7

Please consult ACV's technical Support before making any adjustments. Improper adjustment of CH Proportional Gain could lead to temperature fluctuations and erratic cascade operation.

**CH Integral Gain** allows the cascade response to be adjusted for a central heating call. CH Integral Gain has the greatest influence when the system temperature is close to the setpoint.

Press the **LEFT** or **RIGHT** buttons to adjust the CH Integral Gain then press the **OK** button to store the setting.

#### · Increase CH Integral Gain


- The Cascade System will take longer to reach the setpoint, but setpoint overshooting is minimized.
- If the setpoint is reached too quickly, increase the CH Integral Gain value by 2. Perform Cascade Autodetection and initiate a central heating call. Observe the cascade response and make further adjustments if necessary.

#### Decrease CH Integral Gain

- The Cascade System will reach setpoint faster, but overshooting the setpoint may occur.
- To reach the setpoint faster, decrease the CH Integral Gain value by 2. Perform Cascade Autodetection and initiate a central heating call. Observe the cascade response and make further adjustments if necessary

Default: 245

Please consult ACV's technical Support before making any adjustments. Improper adjustment of CH Integral Gain could lead to temperature fluctuations and erratic cascade operation.



**DHW Proportional Gain** allows the cascade response to be adjusted for a domestic hot water call. DHW Proportional Gain has the greatest influence when the system temperature is far away from the setpoint.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Proportional Gain then press the **OK** button to store the setting.

#### · Increase DHW Proportional Gain

- The Cascade System will reach setpoint faster, but overshooting the setpoint may occur.
- To reach the setpoint faster, increase the DHW Proportional Gain value by 2. Perform Cascade Autodetection and initiate a domestic hot water call. Observe the cascade response and make further adjustments if necessary.

#### · Decrease DHW Proportional Gain

- The Cascade System will take longer to reach the setpoint, but setpoint overshooting is minimized.
- If the setpoint is reached too quickly, decrease the DHW Proportional Gain value by 2. Perform Cascade Autodetection and initiate a domestic hot water call. Observe the cascade response and make further adjustments if necessary.

#### Default: 7

Please consult ACV's technical Support before making any adjustments. Improper adjustment of DHW Proportional Gain could lead to temperature fluctuations and erratic cascade operation.

**DHW Integral Gain** allows the cascade response to be adjusted for a domestic hot water call. DHW Integral Gain has the greatest influence when the system temperature is close to the setpoint.

Press the **LEFT** or **RIGHT** buttons to adjust the DHW Integral Gain then press the **OK** button to store the setting.

#### · Increase DHW Integral Gain

- The Cascade System will take longer to reach the setpoint, but setpoint overshooting is minimized.
- If the setpoint is reached too quickly, increase the DHW Integral Gain value by 2. Perform Cascade Autodetection and initiate a omestic hot water call. Observe the cascade response and make further adjustments if necessary.


#### Decrease DHW Integral Gain

- The Cascade System will reach setpoint faster, but overshooting the setpoint may occur.
- To reach the setpoint faster, decrease the DHW Integral Gain value by 2. Perform Cascade Autodetection and initiate a domestic hot water call. Observe the cascade response and make further adjustments if necessary

Default: 245

Please consult ACV's technical Support before making any adjustments. Improper adjustment of DHW Integral Gain could lead to temperature fluctuations and erratic cascade operation.

Cascade ( ) -->> Cascade Autodetection ( ?)




The Cascade System must be configured after wiring is completed and any required adjustments are made in Cascade Settings. Refer to "Cascade system connection (4-boiler Cascade)" before using this function.

The Cascade Autodetection function automatically finds and configures all boilers in the Cascade System. This eliminates the need to manually configure each boiler of the Cascade System. Select Cascade Autodetection on the Master boiler then follow the on-screen instructions to perform Cascade Autodetection.

Once Cascade Autodetection is finished, a message will be displayed indicating how many boilers have been found. If the number of boilers found is correct, press **OK** to finish Cascade Autodetection.

If the number of boilers found is not correct, check the cascade communication cables between the boilers and repeat Cascade Autodetection process.

#### STRUCTURE OF THE ACVMAX CASCADE MENU




#### GENERAL PROCESS FOR CASCADE INSTALLATION

- 1. Define the number of boilers in the cascade (2 to 4).
- 2. Prepare a cascade mounting rack of the appropriate size, refer to "Assembling the Cascade Mounting rack".
- 3. Install the boilers on the rack using the mounting support of each boiler.
- 4. Define which boiler will be the Master.
- 5. Perform the hydraulic connections of the boilers, refer to "Hydraulic connections of Cascade Systems".
- 6. Perform the chimney connections of the boilers, refer to "Chimney connections of Cascade Systems".
- 7. Perform the electrical connection of the Master boiler, refer to "Cascade system connection (4-boiler Cascade)":
  - Connect the Cascade wiring
  - Connect Heat demand input, outdoors sensor
  - Connect the system sensor
  - Connect the DHW sensor
  - Connect all the system pumps
- 8. Perform the electrical set up of the Slave boiler(s):
  - Connect Cascade wiring
  - Connect appliance pump
- 9. Start the system, refer to <u>"Cascade start-up process"</u>.

#### ASSEMBLING THE CASCADE MOUNTING RACK

The steps in the following procedures are indicated by black circles with a white number (1).




#### 1. Mounting the feet

Required material



Procedure (x2 for each foot)






#### 2. Mounting the vertical profiles and connecting them to the feet

Required material




Procedure (x3 for the configuration on the left)



#### 3. Mounting the horizontal profiles and connecting them to the vertical ones

#### Required material






#### 4. Installing the clips to install the boiler mounting support

#### Required material



#### Procedure



Boiler support bracket, provided with the boiler




#### **HYDRAULIC CONNECTIONS OF CASCADE SYSTEMS**



#### 1. Mounting the pumps on the return connections

Required material




#### 2. Mounting the foot on the heating ramp

Required material



Procedure




#### 3. Mounting the heating ramp on the boilers

Required material





Procedure






#### 4. Mounting the balance header on the system

Required material




#### Procedure










#### **CHIMNEY CONNECTIONS OF CASCADE SYSTEMS**





#### 2. Mounting the pipe supporting rack (2 boiler cascade)

Required material




#### Procedure





#### 2. Mounting the flue pipes on the boilers


Required material






1x

Procedure





#### **CASCADE SYSTEM CONNECTION (4-BOILER CASCADE)**

#### Set-up conditions

- Gas conversion done as required
- Boilers switched off using the ON/OFF master switch
- External power supply closed
- Gas supply closed
- Master boiler of the system defined
- Front panel of the boilers open (refer to the relevant procedure in the Installation, Operation and Maintenance Instructions provided with the boiler)

#### Required accessories

Designation	P/N	QTY
Cascade connection wire harness	257F1166	3

#### **Connection Procedure**





### Refer to the diagram below for a general cascade connection scheme.


- 1. Connect the 4-terminal end connector (3) of the cascade connection harness (1) to the X16 terminal (4) of the electronic board on the Master boiler.
- 2. Route the wire harness as shown in (6).
- Connect the 6-terminal end connector (2) of the cascade connection harness (1) to the socket located at the bottom of the front panel of the boiler, accessing from underneath (5).

#### Follow-on tasks

- 1. Make all the heat demand connections (eg. Room thermostats, sensor connections (DHW sensor, Cascade sensor) and pump connections to the Master appliance (see also following pages for the hydraulic and electrical configurations).
- Connect the local Slave appliance pumps.
- Close the front panel of the boilers.
- 4. Perform Cascade start-up procedure, refer to "Cascade start-up process".










#### **CASCADE START-UP PROCESS**

#### Set-up conditions

- Cascade electrical connection done (Prestige Solo (Pre-set), refer to "Cascade system connection (4-boiler Cascade)").
- Condensate trap full of water
- External power supply open
- · Gas supply open
- Hydraulic circuit(s) full of water

#### Procedure

- 1. Power up all appliances using their ON/OFF master switch.
- 2. Start Cascade autodetection from the Master appliance (See on the right). The Master appliance will then become the electronic master of the system. It will automatically recognize the number of appliances in the cascade.





- 3. Set the maximum appliance power as follows :
  - The master boiler will then calculate the total system capacity based on the defined appliance capacity.
- 4. Set the system parameters on the Master appliance:
  - CH1 curve
  - CH2 curve
  - DHW setpoint

#### Follow-on tasks


None

#### **ACCESSING THE CASCADE AUTODETECTION PAGE**









#### **PRESET CONFIGURATION 2**

3-boiler cascade configuration, high temperature, with DHW circuit


#### **Pump Configuration 2**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	Flame
Error	CH1	CH1/CH2/ DHW	DHW	CH1/CH2/ DHW	Flame





#### General remarks

- Refer to the next page to know how to set up the ACVMax controller.
- For cascade system setup, refer to "Cascade system connection (4-boiler Cascade)".



Master





## ACVMax interface settings using the Installer menu (Installer code needed, see <u>"Installer Code"</u>):

Main Screen	Sub- screen	item	Sub-item	Required selection
	רועט	Model		Prestige Solo (Pre-set)
	Q ·	Pump Settings	Preset Pump Config	Config 2
Ö		Heating Operation		Enabled (##)
Alls		CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
	<b>♣</b>	DHW Operation		Enabled ( )
		Demand		Sensor

#### **Pump Configuration 2**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	Flame
Error	CH1	CH1/CH2/ DHW	DHW	CH1/CH2/ DHW	Flame

#### Slave

Electrical board terminals	Terminal name> Connected to	
	ERR	> None
	DHW	> None
VICE B V B B B B B B B B B B B B B B B B B	CH	> CH pump
×100		

Main Screen	Sub- screen	item	Sub-item	Required selection
	Serv.	Model		Prestige Solo (Pre-set)
		Pump Settings	Preset Pump Config	Config 2
Ö		Heating Operation		Enabled (###)
יער		CH2 Circuit		Enabled
	<b>%</b> ₽	Demand		Thermostat and Outd. curve
	<b>₹</b>	DHW Operation		Enabled (♣)
		Demand		Sensor

3-boiler cascade configuration, high temperature, with DHW circuit


#### **Pump Configuration 2**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	Flame
Error	CH1	CH1/CH2/ DHW	DHW	CH1/CH2/ DHW	Flame





#### General remarks

- Refer to next page to know how to set up of the ACVMax controller.
- For cascade system setup, refer to "Cascade system connection (4-boiler Cascade)".



#### Master





Main Screen	Sub- screen	item	Sub-item	Required selection
	איני איני	Model		Prestige Solo (Pre-set)
		Pump Settings	Preset Pump Config	Config 2
Ö		Heating Operation		Enabled ( )
νων		CH2 Circuit		Enabled
	<b>%</b>	Demand		Thermostat and Outd. curve
	# <del>*</del> <b>*</b> •	DHW Operation		Enabled (♣)
	<b>W</b>	Demand		Sensor

#### **Pump Configuration 2**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	Flame
Error	CH1	CH1/CH2/ DHW	DHW	CH1/CH2/ DHW	Flame

#### Slave

Electrical board terminals	Terminal name> Connected to	
	ERR	> None
VG B B B B B B B B B B B B B B B B B B B	DHW	> None
VIGI	CH	> CH pump
×100		

ACVMax interface settings using the Installer menu (Installer code needed, see <u>"Installer Code"</u>):

Main Screen	Sub- screen	item	Sub-item	Required selection
	ents D	Model		Prestige Solo (Pre-set)
₹Ø;		Pump Settings	Preset Pump Config	Config 2
	<b>@!!!!</b>	Heating Operation		Enabled (

#### **PRESET CONFIGURATION 5**

 $3\mbox{-}boiler$  cascade configuration, with two high temperature heating circuits and DHW circuit


#### **Pump Configuration 5**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	Flame
Error	CH2	CH1	DHW	CH1/CH2/ DHW	Flame




#### General remarks

- Refer to next pageto know how to set up the ACVMax controller.
- For cascade system setup, refer to "Cascade system connection (4-boiler Cascade)".



#### Master



Main Screen	Sub- screen	item	Sub-item	Required selection
	אין איני	Model		Prestige Solo (Pre-set)
	₹©r`	Pump Settings	Preset Pump Config	Config 5
		Heating Operation		Enabled ( )
<b>ب</b> وب		CH2 Circuit		Enabled
		Demand		Thermostat and Outd. curve
	<b>_</b>	DHW Operation		Enabled ( )
	<b>#</b>	Demand		Sensor

#### **Pump Configuration 5**

Flex 4	Flex 6	Flex 3	Flex 2	Flex 1	Flex 5
ERR	P4	P3	DHW	CH	Flame
Error	CH2	CH1	DHW	CH1/CH2/ DHW	

#### Slave

Electrical board terminals	Terminal name> Connected to			
	ERR	> None		
	DHW	> None		
	CH	> CH pump		
×100 <b>©</b>				

ACVMax interface settings using the Installer menu (Installer code needed, see <u>"Installer Code"</u>):

Main Screen	Sub- screen	item	Sub-item	Required selection
	ANTA DE	Model		Prestige Solo (Pre-set)
Ö	\$Q\$	Pump Settings	Preset Pump Config	Config 5
Alla	*****	Heating Operation		Enabled ( <b>)</b>
	<i>₩</i>			
		CH2 Circuit		Enabled

# THE INSTALLER'S HANDBOOK FOR HEATING SYSTEMS CONTROLLED WITH ACVMAX

# VOLUME 4 Chimney Connections



Prestige 24 - 32 Solo /Excellence Prestige 42 - 50 - 75 - 100 - 120 Solo HeatMaster 25 C HeatMaster 25 - 35 - 45 - 70 - 85 - 120 TC WaterMaster 25 - 35 - 45 - 70 - 85 - 120

Applicable to appliances manufactured from March 2016, equipped with at least software version (DSP) 3.05



#### **VOLUME 4 - CHIMNEY CONNECTIONS**

CHIMNEY CONNECTION CHARACTERISTICS FOR PRESTIGE BOILERS	4-3
CALCULATION OF FLUE PIPE SYSTEM - PRESTIGE APPLIANCES	4-4
Calculation of the Flue Pipe Length	4-4
CHIMNEY CONNECTION CHARACTERISTICS FOR HEATMASTER AND WAT MASTER APPLIANCES	
CALCULATION OF FLUE PIPE SYSTEM - HEATMASTER AND WATERMASTER	
Calculation of the flue pipe length	4-7
Cascade: calculation of the maximum length of flue pipes	4-8

For more information on cascade installation of Prestige 42 - 50 - 75 - 100 - 120 Solo, refer to Volume 3, "Chimney connections of Cascade Systems".

#### FLUE PIPE CONNECTION TYPES - PRESTIGE SOLO AND EXCELLENCE

#### 逐

#### It is mandatory to use ACV flue systems to connect the appliance.

**B23P:** : Connection to a combustion product exhaust system designed to operate with positive pressure.

**B23** : Connection to an exhaust duct that discharges the combustion products outside the room where it is installed, with the combustion air being drawn directly from the boiler room.

**C13(x)** : Connection using pipes fitted with a horizontal terminal that simultaneously takes in combustion air for the burner and discharges combustion products outside through openings that are either concentric or close enough together to be subjected to similar wind conditions, i.e. openings shall fit inside a square of 50 cm for boilers up to 70 kW and inside a square of 100 cm for boilers above 70 kW.

C33(x) : Connection using pipes fitted with a vertical terminal that simultaneously takes in fresh air for the burner and discharges combustion products outside through openings that are either concentric or close enough together to be subjected to similar wind conditions, i.e. openings shall fit inside a square of 50 cm for boilers up to 70 kW and inside a square of 100 cm for boilers above 70 kW.

C43(x) : Connection using two pipes to a collective duct system serving more than one appliance; this system of collective ducts features two pipes connected to a terminal unit that simultaneously takes in fresh air for the burner and discharges the combustion products outside through openings that are either concentric or close enough together to be subjected to similar wind conditions. C43(x) boilers are suitable for a connection to a natural draught chimney only.

**C53(x)** : Connection to separate ducts for supplying combustion air and discharging combustion products; these ducts may end in zones with different pressure levels, but are not allowed to be installed on opposite walls of the building.


C63(x): Type C boiler meant to be connected to a system for supplying combustion air and discharging combustion products, that is approved and sold separately (Prohibited in some countries (e.g. Belgium) - refer to local regulations and standards in force). Terminals for the supply of combustion air and for the evacuation of combustion products are not allowed to be installed on opposite walls of the building. See also the following additional specifications:


- Maximum allowable draught is 200 Pa.
- Maximum allowable pressure difference between combustion air inlet and flue gas outlet (including wind pressures) is (including wind pressures) is 150 Pa (for P24/P32/P42/P50/P75) and 180 Pa (for P100/P120).
- Condensate flow is allowed into the appliance.
- Maximum allowable recirculation rate of 10% under wind conditions.

**C83(x)**: Connection using a single or double duct system. The system is made of a normal exhaust flue duct that discharges the combustion products. The appliance is also connected through a second duct fitted with a terminal, that supplies the burner with fresh outdoor air.

C93(x) : Connection using an individual system whose combustion product exhaust duct is installed in an exhaust duct that is integral with the building. The appliance, the exhaust duct and the terminal units are certified as an inseparable assembly. Minimum usable diameter for the vertical duct supplying the combustion air is 100 mm.

The C93 configuration enables airtight operation in a pre-existing chimney. The combustion air crosses the space between the tubing and the pre-existing chimney. Make sure to clean the pre-existing chimney thoroughly prior to installation, especially if there is soot or tar residue. Make sure that there is a clearance area for the combustion air at least equivalent to the area that would have been provided by separate concentric ducts or air intake ducts.






#### CALCULATION OF THE FLUE PIPE LENGTH




When connecting the flue pipes, make sure not to exceed the maximum length recommended for the product, otherwise the system pressure might decrease.

The flue pipe dimensions can be calculated using the method shown on the right. Please refer to the tables on the right indicating the equivalent length in meters of straight pipes, applied to each of the connection components. Then compare the calculation result to the recommended maximum flue pipe length for each type of Prestige model, as indicated below.

		Maximum length of flue pipes (in m) (terminals incl.)									
		Concentric	flue pipe	Single wall	connection	Flex connection					
	Ø 60/100	Ø 80/125	Ø 100/150	Ø 80	Ø 100	Ø 80	Ø 100				
P24	24	105	_	102	_	48	_				
P32	12	56	_	54	_	26	_				
P 42	_	10	25	10	35	5	17				
P 50	_	10	25	10	35	5	17				
P75	_	10	25	10	35	5	17				
P 100	_	_	20	_	30	_	15				
P 120	_	_	20	_	30	_	15				





Tables of equivalent length for the various connection accessories and connection types:

The following tables are based on ACV equipment and cannot be applied as a rule.

	Equivalent length for accessories								
	Prestige 24-32 Solo/Excellence								
	Concentric flue pipe Ø 60/100 mm	Concentric flue pipe Ø 80/125 mm	Parallel flue pipe Ø 80 mm						
1 m straight pipe	1 m	1 m	1 m						
90° elbow	1.4 m	2 m	2.3 m						
45° elbow	1.2 m	1 m	1 m						

	Equivalent length for accessories									
		Prestige 42 - 50 - 75 - 100 - 120 Solo								
	Concentri	c flue pipe	Single wall connection							
	Ø 80/125	Ø 100/150	Ø 80	Ø 100						
1 m straight pipe	1	1	1	1						
90° elbow	1.43	1.72	2.16	3.6						
45° elbow	0.81	1.14	0.91	2.23						
Flex line	-	-	1.93	2.12						



The equivalent length for pipes equipped with a measuring unit is equal to a 1 meter straight pipe

#### Example of calculation in the case of a concentric flue pipe:

This figure shows an example of connection proposed by an installer for a Prestige 50 Solo with a 100/150 concentric flue connection.

The assembly is comprised of: 2 x 90° elbows + 6 meters of straight pipes  $+ 2 \times 45^{\circ}$  elbows.

The installer can check that the connection complies with the recommended value using the method below.


#### Method:

a) Calculate the corresponding length in meters of pipes for the flue pipe assembly:

$$(2 \times 1.72) + (6 \times 1) + (2 \times 1.140) = 11.72 \text{ m}$$

b) Compare the resulting value with the recommended length value (25 m).


The flue pipe length is within the recommended range.




L = equivalent length in meters of straight flue pipes (1 m straight pipe).

#### PRESTIGE SOLO CASCADE: MAXIMUM LENGTH OF FLUE PIPES

Prestige 50 Solo cascade in a C43 chimney connection configuration



Prestige 50 Solo cascade in a B23 chimney connection configuration



Elbow type	150	200
	L. Eq.	L. Eq.
45° [M]	1.7	3.8
90° [M]	4.0	5.8

			Ø of horizor	ntal/vertica	tal/vertical ducts in mm			
Nb of boilers	Prestige Solo	150	150/200**	200	200/250	200/300		
7	120	_	_	_	_	30 m		
6	120	_	_	_	30 m	30 m		
5	120	_	_	15 m	30 m	30 m		
4	120	_	25 m	30 m	30 m	30 m		
3	120	_	30 m	30 m	30 m	30 m		
8	75		_		_	30 m		
7	75	_	_	_	30 m	30 m		
6	75		_	5 m	30 m	30 m		
5	75	_	_	30 m	30 m	30 m		
4	75	_	30 m	30 m	30 m	30 m		
8	50	_	_	_	30 m	30 m		
7	50	_	_	20 m	30 m	30 m		
6	50	_	_	30 m	30 m	30 m		
5	50	_	30 m	30 m	30 m	30 m		
4	50	20 m	30 m	30 m	30 m	30 m		
8	42		_	_	30 m	30 m		
7	42	_	_	20 m	30 m	30 m		
6	42		_	30 m	30 m	30 m		
5	42	_	30 m	30 m	30 m	30 m		
4	42	20 m	30 m	30 m	30 m	30 m		

<sup>\*</sup>This table is for systems comprised of appliances with identical power. For any other configuration, please refer to your ACV representative.

<sup>\*\*</sup>Dn 150/200 : Hor. = 150 mm, Vert.=200 mm

#### FLUE PIPE CONNECTION TYPES - HEATMASTER C AND TC AND WATERMASTER

#### It is mandatory to use ACV flue systems to connect the appliance.

: Connection to a combustion product exhaust system designed to operate with positive pressure.

: Connection to an exhaust duct that discharges the combustion products outside the room where it is installed, with the combustion air being drawn directly from the boiler room.

C13(x) : Connection using pipes fitted with a horizontal terminal that simultaneously takes in combustion air for the burner and discharges combustion products outside through openings that are either concentric or close enough together to be subjected to similar wind conditions, i.e. openings shall fit inside a square of 50 cm for boilers up to 70 kW and inside a square of 100 cm for boilers above 70 kW.

C33(x) : Connection using pipes fitted with a vertical terminal that simultaneously takes in fresh air for the burner and discharges combustion products outside through openings that are either concentric or close enough together to be subjected to similar wind conditions, i.e. openings shall fit inside a square of 50 cm for boilers up to 70 kW and inside a square of 100 cm for boilers above 70 kW.

C43(x) : Connection using two pipes to a collective duct system serving more than one appliance; this system of collective ducts features two pipes connected to a terminal unit that simultaneously takes in fresh air for the burner and discharges the combustion products outside through openings that are either concentric or close enough together to be subjected to similar wind conditions. C43(x) boilers are suitable for a connection to a natural draught chimney only.

C53(x): Connection to separate ducts for supplying combustion air and discharging combustion products; these ducts may end in zones with different pressure levels, but are not allowed to be installed on opposite walls of the building.

C63(x): Type C boiler meant to be connected to a system for supplying combustion air and discharging combustion products, that is approved and sold separately (Prohibited in some countries (e.g. Belgium) - refer to local regulations and standards in force). Terminals for the supply of combustion air and for the evacuation of combustion products are not allowed to be installed on opposite walls of the building. See also the following additional specifications:

• Maximum allowable draught is 200 Pa.

Maximum allowable pressure difference between combustion air inlet and flue gas outlet (including wind pressures) is as follows: 95 Pa (HM 25 TC/25 C, WM 25), 130 Pa (HM 35-45 TC, WM 35-45), 110 Pa (HM 70 TC, WM 70), 160 Pa (HM 85 TC, WM 85) and 170 Pa (HM 120 TC, WM 120).

Condensate flow is allowed into the appliance.

Maximum allowable recirculation rate of 10% under wind conditions.

C83(x) : Connection using a single or double duct system. The system is made of a normal exhaust flue duct that discharges the combustion products. The appliance is also connected through a second duct fitted with a terminal, that supplies the burner with fresh outdoor air. Please contact your ACV representative for the meters of flue pipes that can be used to connect the appliance(s).


C93(x) : Connection using an individual system whose combustion product exhaust duct is installed in an exhaust duct that is integral with the building. The appliance, the exhaust duct and the terminal units are certified as an inseparable assembly. Minimum usable diameter for the vertical duct supplying the combustion air is 100 mm.

The C93 configuration enables airtight operation in a pre-existing chimney. The combustion air crosses the space between the tubing and the pre-existing chimney. Make sure to clean the pre-existing chimney thoroughly prior to installation, especially if there is soot or tar residue. Make sure that there is a clearance area for the combustion air at least equivalent to the area that would have been provided by separate concentric ducts or air intake ducts.

Main Charac	teristics		HM 2 HM 2 WW	25 TC	HM 3				45 TC Л 45			70 TC 1 70	HM 8		HM 1 WM	20 TC 120
Λ:::/fl.::- :: Ø	concentric	mm	80/	125	80/	125		80/	125		100	/150	100/	150	100	/150
Air/flue pipe Ø	parallel	mm	80/	/80	80,	/80		80	/80		100	/100	100/	100	100	/100
Max. allowed flu pressure drop	x. allowed flue pipe Pa 95 130 130			1	10	16	50	17	70							
Max recomme concentric flue p length in meters Ø 80/125, termin	ipe (correspo	onding ipes) *	6	0	3	9	22		_		_					
Max recomme concentric flue p length in meters Ø 100/150, term	ipe (correspo	nding ipes) *	13	30	9	0	53		2	0	1	9	1	8		
Max recommended length (corresponding length in met		ters of	Paral. Ø 80		Paral. Ø 80								Paral. Ø 100			
straight pipes) *	_		56	26	37	17	19	9	76	34	17	8	17	8	9	4
Available conne	ection types			B2	23 - B23	3P - C1	3(x) - C	33(x) -	C43(x	) - C53(	(x)** - (		- C83(x	) - C93	(x)	

See next page to calculate the flue pipe length.

\*\* A C53 connection of the HeatMaster 25C, HeatMaster TC or WaterMaster appliances requires an optional accessory.



#### CALCULATION OF THE FLUE PIPE LENGTH



When connecting the flue pipes, make sure not to exceed the maximum flue pipe length, recommended for the product, otherwise the system pressure might decrease.

The flue pipe length can be calculated using the method shown below. Please refer to the tables below indicating the values in meters, applied to each of the connection components. Then compare the calculation result to the recommended maximum flue pipe length indicated in the table on previous page.

	Flue pipe length (L) (corresponding length in meters of straight pipe)									
	HM 25 HM 25 - 35 WM 25 - 3	- 45 TC	HM 2 HM 25 - 35 - 45 - 7 WM 25 - 35 - 45	70 - 85 - 120 TC						
	Concentric flue pipe Ø 80/125 mm	Parallel flue pipe Ø 80 mm	Concentric flue pipe Ø 100/150 mm	Parallel flue pipe Ø 100 mm						
1 m straight pipe	1 m	1 m	1 m	1 m						
90° elbow	2 m	2.2 m	3.7 m							
45° elbow	2.3 m									



The equivalent length for pipes equipped with a measuring unit is equal to a 1 meter straight pipe

Example of verification of the flue pipe length (L) in a concentric flue pipe system for HeatMaster 25 C / HeatMaster 25 TC / WaterMaster 25 (80/125):


The method is explained through an example. Figure 1: The assembly is comprised of:


1 pipe with a measurement unit + 3 x 90° elbows + 6 meters of straight pipes + 2 x 45° elbows

- · Method:
- a) Using the above table, calculate the length in meters of the whole flue pipe assembly:

$$1 + (3 \times 2) + (6 \times 1) + (2 \times 1) = 15 \text{ m}$$


b) Compare the resulting value with the maximum length (60 m). This flue pipe length is within the recommended range.





### HEATMASTER/WATERMASTER CASCADE: MAXIMUM LENGTH OF FLUE PIPES


 $Heat Master\ 25\ -\ 35\ TC\ /\ Water Master\ 25\ -\ 35\ cascade\ in\ a\ C43\ chimney\ connection\ configuration$ 





Make sure to install an external non-return valve on the flue connection. Please contact your ACV representative for the correct accessory.

HeatMaster / WaterMaster cascade in a B23 chimney connection configuration





Make sure to install an external nonreturn valve and a cascade flue pipe kit. Please contact your ACV representative for the correct accessory.

Elbow type	150	200
	L. Eq.	L. Eq.
45° [M]	1.7	3.8
90° [M]	4.0	5.8

Qty	Appliance type* (HM TC / WM)	Maximum length in M.		
		Dn 150	Dn 150/200**	Dn 200
2	25 - 35 - 45 - 70 - 85	30	30	30
	120	_	30	30
3	25 - 35 - 45	30	30	30
	70	25	30	30
	85	26	30	30
	120	_	_	_
4	25 - 35 - 45	30	30	30
	70	_	30	30
	85	_	30	30
	120	_	_	_
5	25 - 35 - 45	30	30	30
	70	_	30	30
	85	_	6	30
	120	_	_	_
	25 - 35	30	30	30
6	45	16	30	30
	70	_	_	30
	85		_	13
	120	_	_	_
2 to 6	HM 25 C	30	_	

<sup>\*</sup> This table is for systems comprised of appliances with identical power. For any other configuration, please refer to your ACV representative.

<sup>\*\*</sup>Dn 150/200 : Hor. = 150 mm, Vert.=200 mm

# THE INSTALLER'S HANDBOOK FOR HEATING SYSTEMS CONTROLLED WITH ACVMAX

# VOLUME 5 Troubleshooting



Prestige 24 - 32 Solo / Excellence Prestige 42 - 50 - 75 - 100 - 120 Solo HeatMaster 25 C HeatMaster 25 - 35 - 45 - 70 - 85 - 120 TC WaterMaster 25 - 35 - 45 - 70 - 85 - 120

Applicable to appliances manufactured from March 2016, equipped with at least software version (DSP) 3.05



#### **VOLUME 5 - TROUBLESHOOTING**

BLOCKAGE AND ERROR CODES ......5-3

Codes	Description of the fault	Solution for the fault
E 01	Failed ignition: The burner failed to light after 5 ignition attempts.	<ol> <li>Check gas supply to appliance.</li> <li>Check Ignition cable connection in control box.</li> <li>Check electrode for defects, and distance between the pins.</li> <li>Check gas valve and electrical connections to gas valve.</li> </ol>
E 02	False flame: Flame detected prior to ignition.	<ol> <li>Check good electrical ground connection to unit.</li> <li>Check electrode for pollution and deposition of dirt.</li> </ol>
E 03	<b>High Boiler temp.</b> : The boiler temperature exceeds 105°C	Correct condition which caused high temperature or limit to open.  1. Check water flow in the system (radiator valves).  2. Check Pump and pump electrical connections.
E 05	Blower speed: Blower speed not correct or speed signal is not received by ACVMax.	<ol> <li>Check blower and wiring harness.</li> <li>Under normal condition if actual fan speed is 1000 rpm different from set fan speed an error is displayed (after 60sec in running and after 30 sec. at startup).</li> <li>Only exception when actual fan speed &gt; 3000 rpm at max. PWM.</li> </ol>
E 07	High Flue temp.: Flue temperature exceeds high limit.	<ol> <li>Heat exchanger may require cleaning.</li> <li>Appliance will automatically reset once flue temperature returns to normal range.</li> </ol>
E 08	Flame Circuit Error: Flame circuit test failed	Turn appliance off.     Check and clean the electrode.     Check ignition and grounding cables are firmly connected.
E 09	Gas valve circuit error: Gas valve circuit test failed.	<ol> <li>Check the gas valve and wiring harness.</li> <li>If the problem persists replace the "ACVMax" circuit board.</li> </ol>
E 12	Internal Fault: EEPROM misconfiguration	Turn unit off and on to resume normal operation.     If the problem persists replace the "ACVMax" circuit board.
E 13	Reset limit reached: Resets are limited to 5 every 15 minutes.	<ol> <li>Turn unit off and on to resume normal operation.</li> <li>If the problem persists replace the "ACVMax" circuit board.</li> </ol>
E 15	Sensor Drift: Supply or return sensor reading has drifted.	Check supply and return temperature sensors and wiring harness.
E 16	Supply Sensor Stuck: Supply sensor reading is not changing.	Check supply temperature sensor and wiring harness for shortcuts or other defects.     Check waterflow and the temperature balance in the system, because CH supply temperature does not change.
E 17	Return Sensor Stuck: Return sensor reading is not changing.	<ol> <li>Check return temperature sensor and its position, check wiring harness for shortcuts or other defects.</li> <li>Check waterflow and the temperature balance in the system, because CH return temperature does not change.</li> <li>Failure may happen at low output capacity when supplying from a big tank!</li> </ol>
E 18	Sensor Failure: Supply or return sensor reading changed very rapidly.	Check supply and return temperature sensors and wiring harness.
E19	Flame Failure: Flame failure during start up phase	Flame loss after start up of the appliance.  1. Check the flue system for blockage and check the adjustment of the appliance (CO2 high 8.8 +/-0.2%, CO2 low 8.6+/-0.2% measured with front casing open).  2. Also check the Ignition / Ionisation rod (distance to the burner / pollution)
E 21	Internal Control Fault: A / D conversion error.	Turn unit off and on then press OK to resume normal operation.
E 25	Internal Control Fault: CRC check error.	Turn unit off and on to resume normal operation.
E 30	<b>Supply Sensor Shorted</b> : A short circuit has been detected in the appliance supply temperature sensor circuit	<ol> <li>Check supply temperature sensor and wiring harness for a short circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem, reset the appliance and resume normal operation.</li> </ol>

Codes	Description of the fault	Solution for the fault	
E 31	<b>Supply Sensor Open</b> : An open circuit has been detected in the appliance supply temperature sensor circuit	<ol> <li>Check supply temperature sensor, connectors and wiring harness for an open circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E 32	<b>DHW Sensor Shorted:</b> A short circuit has been detected in the DHW temperature sensor circuit	1. Check DHW temperature sensor and wiring harness for a short circuit. 2. If necessary replace the sensor, or the wire harness. 3. After fixing the problem reset the appliance and resume normal operation.	
E 33	<b>DHW Sensor Open</b> : An open circuit has been detected in the DHW temperature sensor circuit	<ol> <li>Check DHW temperature sensor, connectors and wiring harness for an open circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E 34	Low Voltage: Line voltage has fallen below an acceptable operating level.	The appliance will automatically reset once line voltage returns to normal.	
E 37	Low Water: Water level has fallen below 0.7 bar.	<ol> <li>Increase pressure to normal range.</li> <li>The appliance will automatically reset once water level returns to normal.</li> </ol>	
E 43	<b>Return Sensor Shorted</b> : A short circuit has been detected in the appliance return temperature sensor circuit.	<ol> <li>Check return temperature sensor and wiring harness for a short circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem, reset the appliance and resume normal operation.</li> </ol>	
E 44	<b>Return Sensor Open:</b> An open circuit has been detected in the appliance return temperature sensor circuit.	<ol> <li>Check return temperature sensor, connectors and wiring harness for an open circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem, reset the appliance and resume normal operation.</li> </ol>	
E 45	Flue Sensor Shorted: A short circuit has been detected in the appliance flue temperature sensor circuit	<ol> <li>Check flue temperature sensor and wiring harness for a short circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E 46	Flue Sensor Open: An open circuit has been detected in the appliance flue temperature sensor circuit.	<ol> <li>Check flue temperature sensor, connectors and wiring harness for an open circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E47	Water pressure sensor error: Water pressure sensor is disconnected or broken	<ol> <li>Check water pressure sensor, connectors and wiring harness.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E 76	Gas pressure switch open	<ol> <li>Check both the static and the dynamic gas pressures.</li> <li>Correct condition which caused the pressure switch to open</li> <li>Appliance will automatically reset once the pressure switch is closed.</li> </ol>	
270	External Limit Open: An external automatic reset appliance limit has opened.	<ol> <li>Correct condition which caused limit to open.</li> <li>Appliance will automatically reset once external limit closes</li> </ol>	
E 77	High temperature mixing circuit	Check if the mixing valve functions correctly.	
E 78	Mix circuit sensor shorted	<ol> <li>Check Mix circuit temp. sensor and wiring harness for a short circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E 79	Mix-circuit sensor Open	<ol> <li>Check Mix circuit temp. sensor and wiring harness for an open circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>	
E 80	<b>Return &gt; Supply</b> : Return temperature is higher than supply temperature.	Confirm water flows in appliance return and out appliance supply.	
E 81	Sensor Drift: Supply and return temperatures are not equal.	<ol> <li>Check water is flowing through appliance.</li> <li>Wait a few minutes for the water to equalise the temperature, the appliance will automatically reset once temperatures become equal.</li> <li>If appliance doesn't reset, check the NTC's and check the wire harness, replace if necessary.</li> </ol>	

Codes	Description of the fault	Solution for the fault
E82	Delta T protection blocking - Delta T too high	Verify flow in the system.     Check pump for blockage and obstructions, unblock it as required. Replace if neccessary.
E83	Delta T protection Lock-out - Lock-out due to Delta T value.	<ol> <li>Verify flow in the system.</li> <li>Check pump for blockage and obstructions, unblock it as required. Replace if neccessary.</li> </ol>
E 85	Pump operation: warning - Appliance pump is running out of limits.	Pump is running out of its limits. Check pump for blockage and obstructions, replace if neccessary
E 86	Pump hard fault: Pump Failure	Pump Failure, check if pump PWM-feedback wire is properly connected, replace pump when neccessary
E 87	External Limit Open: An external appliance limit has opened.	<ol> <li>Correct condition which caused limit to open, then reset appliance.</li> <li>The appliance needs to be reset once external limit closes.</li> </ol>
E88	Pump Blocking: Pump attempts to restart.	Check pump for blockage and obstructions, unblock it as required. Replace if neccessary.
E 89	Incorrect Setting: A parameter setting is outside the settings range.	<ol> <li>Review CH &amp; DHW settings and correct as necessary.</li> <li>The appliance will automatically reset once corrected.</li> </ol>
E 90	<b>Firmware Mismatch:</b> Control module and display firmware versions are incompatible.	One or several components are not compatible with the system. Replace mismatched component(s).
E 91	<b>System Sensor Shorted</b> : A short circuit has been detected in the system temperature sensor circuit	<ol> <li>Check system temperature sensor and wiring for a short circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>
E 92	<b>System Sensor Open</b> : An open circuit has been detected in the system temperature sensor circuit.	<ol> <li>Check system temperature sensor and wiring for an open circuit.</li> <li>If necessary replace the sensor, or the wire harness.</li> <li>After fixing the problem reset the appliance and resume normal operation.</li> </ol>
E 93	<b>Outdoor Sensor Shorted</b> : A short circuit has been detected in the outdoor temperature sensor circuit.	Check outdoor temperature sensor and wiring for a short circuit.     If necessary replace the sensor, or the wire harness.     After fixing the problem reset the appliance and resume normal operation.
E 94	Internal Display Fault: Display memory error	Turn unit off and on to resume normal operation.
E 95	Supply Sensor Error: Supply sensor reading is invalid	Check wiring between display and control module.     If necessary replace the sensor, or the wire harness.     After fixing the problem reset the appliance and resume normal operation.
E 96	<b>Outdoor Sensor Open</b> : An open circuit has been detected in the outdoor temperature sensor circuit.	1. Check outdoor temperature sensor and wiring for an open circuit. 2. If necessary replace the sensor, or the wire harness. 3. After fixing the problem reset the appliance and resume normal operation.
E 97	Cascade Mismatch: Cascade configuration has changed.	Run autodetection if change was intentional, or else check wiring between appliances.     Appliance will automatically reset once repaired.
E 98	Cascade Bus Error: Communication with other appliances has been lost.	Check wiring between appliances.     Appliance will automatically reset once repaired.
E 99	Controller Bus Error: Communication between appliance display and control module has been lost.	Check wiring between components.     Appliance will automatically reset once repaired.

